

APPENDIX K

CAMERA/LIGHT BRACKET (P/N 400107)

INSTALLATION INSTRUCTIONS

This procedure is to be performed only by personnel who have received appropriate training.

Step-by-Step Assembly Instructions



Step 1: Remove two retainer port screws (11) from top corner of helmet using a Phillips #3 screwdriver.



NOTE: Brackets may be bent to shape as required.



Step 2: Line up bracket holes with helmet retainer holes.



Step 3: Replace the two retainer port screws (11) and tighten using a Phillips #3 screwdriver to 45 in.lbs (5 Nm).



Step 4: Right hand bracket installed.



Step 5: Left hand bracket installed.



Step 6: Left and Right brackets.