

6 Simple Steps to Install Silicone Neck Seal on Neck Ring



Step 1:

Place silicone neck seal onto neck ring, making sure double square grooves align on both neck seal and neck ring.

Attach medium-sized binder clip onto silicone neck seal on neck ring.



Step 2:

Two hands are recommended to install silicone neck seal onto neck ring.

With first hand, hold neck seal grooves firmly against double square grooves of neck ring. With second hand, stretch lower portion of neck seal around neck ring.



Step 3:

Continue to hold neck seal grooves firmly against double square grooves of neck ring while you work your way around neck ring.



Step 4:

During final stages of securing silicone neck seal to neck ring, keep aligning double square grooves of both silicone neck seal and neck ring for perfect fit.



Step 5:

When silicone neck seal is fully and securely attached to neck ring, you may remove medium-sized binder clip.



Step 6:

Neck seal is now securely attached to neck ring and installation process is complete.