



**Divator Full Face Mask**


---

2025 September

# READ BEFORE USE

1. Only holders of a valid Interspiro Service Certificate may carry out service and repairs on Interspiro breathing equipment. Unauthorized service may result in malfunction and users relying thereon could sustain severe respiratory injury or death.
2. When using the spare part list always refer to the equipment's Service manual in regard to procedures and handling of the spare parts assembly and function.
3. Changes to this document – necessitated by typographical errors, inaccuracies of current information or improvements and changes of equipment – may be done at any time and without prior notice. Always refer to the Interspiro webpage for the latest version.
4. The description defines if the spare part is a multi-pack, e. g. "10 x 336100437" indicates that this is a multi-pack that consists of 10 pieces of the single component 336100437. The single component part number 336100437 can not be ordered, it is only used to label parts included in service kits.
5. The service kits contain replacement items used for preventive maintenance.
6. Always refer to the Interspiro webpage for product and document updates and important notices.


# Spare Parts Divator Full face mask




## Spare Parts Divator Full face mask

| Position | Item number      | Description                                                           |
|----------|------------------|-----------------------------------------------------------------------|
| 1        | <b>460190404</b> | Service kit Divator Full Face Mask & Spiromatic mask with blank cover |
| 2        | <b>97220-01</b>  | Service kit Divator Hatch                                             |
| 3        | <b>97203-51</b>  | Valve disc Divator Hatch                                              |
| 4        | <b>460190457</b> | Head harness Divator, black, natural rubber                           |
| 5        | <b>460190541</b> | Buckle assy, 5 x 336900017                                            |
| 6        | <b>32419-52</b>  | Non-return valve disc, 1x32419-01                                     |
| 7        | <b>460190549</b> | Valve seat assy, black, 2-pack                                        |
| 8        | <b>460190555</b> | Blank cover for mask, black                                           |
| 9        | <b>336190222</b> | O-ring, 5 x 944610221                                                 |
| 10       | <b>460200079</b> | Inner mask, silicone, black                                           |
| 11       | <b>460190398</b> | Retaining plate Replaces 336100018                                    |
| 12       | <b>336190246</b> | Screw, 10 x 941136224                                                 |
| 13       | <b>336190850</b> | Divator Visor                                                         |
| 14       | <b>460190547</b> | Frame kit for Divator visor, black                                    |
| 15       | <b>336190409</b> | Screw with washer, 10-pack                                            |
| 16       | <b>336190554</b> | Spacer, 10-pack, replaces 336100890                                   |
| 17       | <b>88542-51</b>  | Pressure equalizing pad, four slots                                   |
| 18       | <b>460190510</b> | Holder                                                                |
| 19       | <b>336190489</b> | Screw, 10 x 941136226                                                 |
| 20       | <b>336190373</b> | Pressure equalizing pad, standard with four slots                     |
| 21       | <b>460190513</b> | Pressure Equalizing Pad for OTS microphone                            |
| 22       | <b>96962-01</b>  | Visor with mounted Hatch                                              |




# Spare Parts Divator breathing valve



**Service kit**  
Divator breathing valve  
with normal pressure



**Service kit**  
Divator breathing valve  
with safety pressure



## Spare Parts Divator breathing valve

| Position | Item number      | Description                                                       |
|----------|------------------|-------------------------------------------------------------------|
| 1        | <b>460190902</b> | Service kit for 1 Divator breathing valve without safety pressure |
| 2        | <b>460190904</b> | Service kit for 1 Divator breathing valve with safety pressure    |
| 3        | <b>336101155</b> | Exhalation unit, without safety pressure, black                   |
| 4        | <b>460190552</b> | Exhalation unit, SP, Black                                        |
| 5        | <b>336190487</b> | Purge button, 5 x 336100432                                       |
| 6        | <b>346190197</b> | Shield ring, black 5-pack (5 x 336800184)                         |
| 7        | <b>460190518</b> | Cover with purge button, black                                    |
| 8        | <b>460190721</b> | Guide disc Divator, BV, NP                                        |
| 9        | <b>460190412</b> | Guide disc with SP Replaces 336100003                             |
| 10       | <b>460190500</b> | Sealing spring, without SP, 5 x 333100056                         |
| 11       | <b>460190508</b> | Sealing spring, SP, 5 x 336100436                                 |
| 12       | <b>460190393</b> | Sealing disc, 5-pack (5 x 336100005)                              |
| 13       | <b>30005-51</b>  | Exhalation diaphragm 5-pack Natural rubber, black                 |
| 14       | <b>460190413</b> | Securing ring 10-pack (10 x 336100008)                            |
| 15       | <b>336190638</b> | Washer, 10 x 336100437                                            |
| 16       | <b>460190140</b> | Diaphragm for breathing valve, (1 x 336100009)                    |
| 17       | <b>336190224</b> | O-ring, 5 x 336900009                                             |
| 18       | <b>460190515</b> | Locking ring, black, 5 x 336101139                                |
| 19       | <b>336190360</b> | Diaphragm unit MK II                                              |
| 20       | <b>336101156</b> | Valve housing assy MKII, black, without safty pressure            |
| 21       | <b>336101158</b> | Valve housing assy MK II with safety pressure, black              |
| 22       | <b>336190226</b> | O-ring, 10 x 336900008                                            |
| 23       | <b>460190559</b> | Non return valve assy                                             |
| 24       | <b>460190516</b> | Locking nut, black, 5 x 336101140                                 |
| 25       | <b>460190558</b> | Valve insert Divator w/o SP                                       |

## Spare Parts Divator breathing valve

| Position | Item number      | Description                               |
|----------|------------------|-------------------------------------------|
| 26       | <b>336190357</b> | Valve insert with safety pressure         |
| 27       | <b>97083-51</b>  | Valve insert subassy with normal pressure |
| 28       | <b>97028-51</b>  | Valve insert subassy with safety pressure |
| 29       | <b>346190198</b> | Retaining ring 10-pack 10 x 336100777     |
| 30       | <b>96341-52</b>  | Connection nipple, green O-ring           |
| 31       | <b>96341-51</b>  | Connection nipple, black O-ring           |
| 32       | <b>336190227</b> | O-ring, 10 x 331900064                    |
| 33       | <b>99486-51</b>  | O-ring , green, 10 x 99486-01             |
| 34       | <b>336190228</b> | O-ring, 12.42x1.78, NBR, 10 x 336900007   |
| 35       | <b>336190225</b> | O-ring, 10 x 336900001                    |
| 36       | <b>32408-51</b>  | Lever assembly with adjustment screw      |
| 37       | <b>460190511</b> | Sealing plug, 5 x 336100509               |