



# TUBE FITTINGS

## PNTX Plug



Size	S/S	Brass
2	●	
3	●	
4	●	●
5	●	
6	●	●
8	●	●
10	●	●
12	●	
16	●	

## VTX Male 45 ° Elbow




Size	S/S	Brass
4	●	●
4-4	●	●
5		●
6	●	●
6-2		●
6-6	●	●
8	●	●
8-8	●	●
10		●
12	●	●
16	●	●

With nut and sleeve order VBTX.

## WNTX


### Bulkhead Union 45 ° Elbow



Size	S/S	Brass
4	●	
6	●	
8	●	

With nut and sleeve order WNBTX. With locknut add WLN to part number.

## RTX Male Run Tee



Size	S/S	Brass
4	●	●
4-4-4	●	
5		●
6	●	●
6-6-6	●	
8	●	●
8-8-8	●	
12	●	


With nut and sleeve order RBTX.

## WLN Bulkhead Locknut



Size	S/S	Brass
4	●	●
5	●	●
6	●	●
8	●	●
10	●	●
12	●	●
14	●	●
16	●	
20	●	
24	●	


## BTX Nut



Size	S/S	Brass
2	●	●
3	●	●
4	●	●
5	●	●
6	●	●
8	●	●
10	●	●
12	●	●
14	●	●
16	●	●
20	●	●
24	●	●
32	●	

## WTX Bulkhead Union


(With locknut add WLN to part no.)



With nut and sleeve order WBTX.

Size	S/S	Brass
4	●	●
5		●
6	●	●
8	●	●
10	●	●
12	●	●
16	●	


## WETX Bulkhead Union Elbow



With nut and sleeve order TRBTX.


Size	S/S	Brass
4	●	●
6	●	●
8	●	●
10	●	
12	●	

## TX Sleeve (Ferrule)



Size	S/S	Brass
2	●	●
3	●	●
4	●	●
5	●	●
6	●	●
8	●	●
10	●	●
12	●	●
14	●	●
16	●	●
20	●	●
24	●	●
32	●	

## STX Male Outlet Tee




With nut and sleeve order SBTX.

Size	S/S	Brass
4	●	●
4-4-4	●	
5		●
6	●	●
6-6-6	●	
8	●	●
8-8-8	●	●
10		●
12	●	

## WGTX


### Female Bulkhead Connector



With nut and sleeve order WGBTX.

Size	S/S	Brass
4	●	
4-4	●	
6	●	
8	●	
10	●	
12	●	

## WJTX Bulkhead Branch Tee



Size	S/S	Brass
4	●	
6	●	

With nut and sleeve order WJBTX. With locknut add WLN to part number.

● = Standard Fittings readily available    No bullet indicates not available or special order item