

APPENDIX TO M105 DIGITAL
MANUAL

OCEANREEF[®]
connecting divers

M105 DIGITAL

DUAL CHANNEL
W/BATTERY LEVEL TESTER





Congratulations on purchasing the M-105 Digital DC W/BATTERY LEVEL TESTER!
This unit has the same features as the M-105 Digital with the addition of a 2nd communication channel.

Operation

1. Turn on the unit as you would the conventional M-105 Digital.
2. A recording will inform you that you are operating on "channel 1" (32.768 KHz). This is the default frequency.
3. If you wish to switch to "channel 2" press the button indicated in the picture. You will hear a recording say "channel 2."

WARNINGS

On each frequency you may only communicate with units using the same frequency.
It is NOT possible to communicate with underwater units operating on a different channel/frequency.

List of channels/frequencies

Channel 1	32.768 KHz
Channel 2	41.000 KHz



OCEAN REEF
Via Arvigo 2, 16010 Genova (Italia)
Phone +39 010 6598 611 Fax +39 010 6598 622
e-mail ocean.reef@oceanreefgroup.com

OCEAN REEF, Inc.
1699 La Costa Meadows Dr. Suite 101 San Marcos, CA 92078
Phone +1 760 744 9430 Fax +1 760 744 9525

OCEAN REEF on the Internet
<http://www.oceanreefgroup.com>

© OCEAN REEF 2008