



Accuro Bellows Pump

6400000

The Dräger Accuro is a bellows type pump that provides one hand operation for difficult to reach areas. A unique internal scissor mechanism ensures a uniform, even pump stroke, delivering 100 cubic centimeters of sample air. The Accuro Pump is used with short-term Dräger Tubes which forms an integral sampling system.

Features

- Dräger Accuro is a bellows type pump that provides one hand operation
- Unique internal scissor mechanism ensures a uniform, even pump stroke, delivering 100 cubic centimeters of sample air
- Used with short-term Dräger Tubes which forms an integral sampling system

Accuro Bellows Pump Hard Side Kit: Part Number 4056443 Includes

- Accuro Pump: Part Number 6400000
- Tube Opener: Part Number 6401200
- Extension Hose Adapter: Part Number 6400076
- Spare Parts Kit: Part Number 6400220
- Rubber Caps (10/Pkg): Part Number CH16631
- Molded Plastic Transport Case: Part Number 4056442

Accuro Bellows Pump Soft Side Kit: Part Number 4053473 Includes

- Accuro Pump: Part Number 6400000
- Spare Parts Kit: Part Number 6400220
- Screw Driver: Part Number 4053476
- Marker: Part Number 4054199
- Nylon Pouch: Part Number 4594631

Accessories	
6400077	3 Meter Extension Hose
6400078	10 Meter Extension Hose
6400079	15 Meter Extension Hose
CH00213	Hot Air Probe
CH00214	Motor Vehicle Exhaust Probe
Specifications - Accuro Pump 640000	
Dimensions	6.75 in. H x 3.38 in W x 1.75 in. D (170 mm x 85 mm x 45 mm)
Weight	0.5 lbs (225 g)
Stroke Volume	100 mL (+/-5%)



Accuro 2000 Gas Detection System

4500200

Features

- Battery driven electronically controlled instrument which uses the hand held Accuro bellows pump to perform a pre programmed number of strokes
- Requires Accuro P/N 6400000, which is sold separately
- Easy to program - after inserting the Dräger tube, the required number of strokes is programmed and indicated on the LCD

Accuro 2000*: Part Number 4500200 Includes

- Carrying Strap
- Battery Pack: Part Number 6400202
- Battery Charger: Part Number 8316992

*Requires 6400000, sold separately

Accessories	
6400202	Battery Pack
8316992	Battery Charger, U.S.
Specifications	
Dimensions	10.63 in. H x 7.5 in. W x 3.63 in D (270 mm x 190 mm x 100 mm)
Weight	5.25 lbs (2.4 kg)
Program Capability	1- 199 Strokes
Battery	6V, 1Ah max strokes 500 (with battery fully charged)



4056433 HARD SIDE KIT

4053473 SOFT SIDE KIT