

Ronstan snap shackles are made of investment cast 15.5 PH stainless steel for excellent corrosion resistance. All shackle hooks are X-rayed to insure there are no unseen casting flaws. The patented hook portion of a trunnion shackle moves from side to side and the bail portion swivels. Perfect for all applications where two-plan articulation is required for optimum lead. Trunnion Shackles are indicated in the chart with a (T).

Order No.	Deforms at*		Bail Type (T=Trunnion)	Shackle Dimensions (W x H)	Bail Fitting (W x H)	Model No.
	lbs	kg				
NF12000S	2500	1135	S-Bail	3/4 in x 7/8 in	7/16 in x 7/16 in	RF6110
NF12000FR	2500	1135	FR-Bail	3/4 in x 7/8 in	5/8 in x 9/16 in	RF6120
NF12000P	2500	1135	P-Bail	3/4 in x 7/8 in	1/2 in x 5/16 in	RF6130
NF16000S	3000	1360	S-Bail (T)	3/4 in x 3/4 in	7/16 in x 7/16 in	RF6111
NF11000P	3500	1588	P-Bail	5/8 in x 1 1/16 in	7/8 in x 11/16 in	RF6240
NF11000C	3500	1588	P-Bail	5/8 in x 1 1/16 in	3/4 in x 7/16 in	RF6230
NF16100	3600	1650	Fixed Bail	3/4 in x 7/8 in	5/8 in x 3/4 in	RF6100
NF11100	5000	2268	Fixed Bail	5/16 in x 1 1/16 in	3/4 in x 1 1/16 in	RF6200
NF11000S	5000	2268	S-Bail	5/8 in x 1 1/16 in	3/4 in x 3/4 in	RF6210
NF11000FR	5000	2268	FR-Bail	5/8 in x 1 1/16 in	1 1/8 in x 1 in	RF6220
NF14000FR	7000	3175	FR-Bail (T)	1 1/8 in x 1 1/4 in	1 1/8 in x 1 1/16 in	RF6321
NF15000S	7000	3175	S-Bail	1 1/8 in x 1 1/4 in	3/4 in x 11/16 in	RF6310
NF15000FR	7000	3175	FR-Bail	1 1/8 in x 1 1/4 in	1 1/8 in x 1 1/16 in	RF6320
NF19000S	10000	4540	S-Bail (T)	1 1/4 in x 1 3/8 in	1 in x 1 in	RF6411
NF17000S	14000	6350	S-Bail (T)	1 3/8 in x 1 3/4 in	1 1/16 in x 7/8 in	RF6511

\* "Deforms at" is the load at which the fitting becomes distorted to the point of becoming inoperable. Limiting loads to not over 50% of the deformation point is recommended practice.



"P" BAIL

The "P" Bail features a removable pin and clevis either threaded or held in place with a cotter pin. Designed to be used with a mating surface of 3/8 inch across for greatest strength.



"FR" BAIL

The "FR" Bail features a larger flared ring bail that allows for extra attachments.



"S" BAIL

Ronstan's standard bail. The eye is compact and will swivel under load.



D-RING



D SHACKLE

**D-RING / D SHACKLE STAINLESS STEEL**

Order No.	Material Dia.	Length Inside	Type
HB28	3/16 in.	1 1/2 in.	D-ring
HB174	1/4 in.	2 in.	D-ring
HB-29	5/16 in.	2 3/8 in.	D-ring
RF616		7/16 in.	D Shackle



FIXED BAIL

Use where twist is not a factor. An economical alternative to the swivel snap shackle.



"B" BAIL

The "B" Bail has captive ball bearings in a closed swiveling bail to ensure that the bail swivels under high loads.