

TAPES AND MISCELLANEOUS



Polyken Tape

827-60

Polyken® tape is the strongest and most durable tape for diving umbilicals. Approximately one 60 yard roll can be used to wrap 100 feet of umbilical at 18 inch increments. Excellent resistance against abrasion, moisture, solvents, chemicals, and ultraviolet rays. White colored tape will not loosen or bubble. It has a polyethylene backing as well as synthetic adhesive. The tape is stocked in 2 inch width by 60 yards length.



Duct Tape

DUCT TAPE

Polyken® 223 Duct Tape is a high adhesion silver cloth-backed duct tape which has good tensile strength, good adhesion and tack. The tape is conformable, and will not twist or curl during application. Used for wrapping umbilicals and other applications. Made in the U.S.A.



TAT Heat Shrink Tubing

TAT

Dual wall, encapsulating adhesive polyolefin tubing. As TAT shrinks, the inner adhesive liner melts and flows to seal and encapsulate components or splices.

Part No.	Size	Part No.	Size
TAT-1/8	1/8 in. Dia.	TAT-3/8	3/8 in. Dia.
TAT-3/16	3/16 in. Dia.	TAT-1/2	1/2 in. Dia.
TAT-1/4	1/4 in. Dia.	TAT-3/4	3/4 in. Dia.



Leak Detector

SEE BELOW

Detect leaks in pressurized gas systems. Use Leak Detective to locate fugitive gas emissions in compressed air, oxygen, helium, hydrogen, nitrogen, natural gas, acetylene, and propane systems. Leak Detective is manufactured to meet specification MIL-L-25567D and is available in two types:

- Type 1 is for regular temperature applications 27° F to 200° F (-3° C to 95° C)
- Type 2 is for colder application from -65° F to 200° F (-55° C to 95° C)

Part No.	Size	Type
1LD-E / 8OZ	8 ounce	1
1LD-E / 1G	1 gallon	1
2LD-E / 8OZ	8 ounce	2
2LD-E / 1G	1 gallon	2



Scotchkote Electrical Coating

14853

Scotchkote™ Electrical Coating provides vinyl tapes with an extra oil, moisture and corrosion proof layer of flexible coating for problem areas. A fast drying sealant and bonding compound, Scotchkote™, is provided in a brush top 15 oz. (444 cc) can for quick applications. This item helps prevent cable and connector damage due to corrosive vapors from battery outgassing.



Safety Line

SEE BELOW

Model Type	
POLYPRO-3/8-YEL	Polypro Line 3/8 in. Yellow, Approximate breaking strength 2440 lbs
POLYPRO-1/2-YL	Polypro Line 1/2 in. Yellow, Approximate breaking strength 3780 lbs
1/2-NY-BRAID	1/2 in. Double Nylon Braid Rope, Approximate breaking strength 7300 lbs