

## Remote Cutting Head

SEE BELOW

The remote cutting heads has a hinged head that can be opened for easy cable or bar insertion. The movable blade advances in a shear fashion, to cut the material cleanly. When the cutting pressure is relieved, an internal ram spring retracts the blade. The guillotine cutting style was chosen over scissor type cutting because of its powerful output force, larger cable capacities, compact size, and reliability.



### Ordering Information

Part Number	SP-20	SP-24	SP-24CC	SP-40	SP-55	SP-85	SP-100
Output	4.4 ton	7.8 ton	7.8 Ton	6.28 ton	13.0 ton	2.7 Ton	8.3 Ton
Weight	3 lbs	6 lbs	21 lbs	8.5 lbs	20 lbs	16 lbs	29 lbs
Length	8 in. L	11 in. L	14 in. L	12 in. L	17 in. L	19 in.	24 in.
Replacement Blade	20-07	24-08	24C-08	40-14	55-16	85-12	100-10
Copper / Aluminum Wire	3/4 in. (20 mm)	7/8 in. (22 mm)	DO NOT CUT	1-1/2 in. (40 mm)	2 in. (40 mm)	3 in. (76 mm)	530
Rebar, Ground, Anchor Rod	1/2 in. (14 mm)	5/8 in. (16 mm)	5/8 in. (16 mm)	5/8 in. (16 mm)	3/4 in. (20 mm)	DO NOT CUT	
Aluminum Conductor Steel Reinforced	3/4 in. (20 mm)	7/8 in. (22 mm)	DO NOT CUT	1-1/2 in. (40 mm)	2 in. (2156) (50 mm)	DO NOT CUT	DO NOT CUT
Wire Rope	5/8 in. (20 mm)	7/8 in. (22 mm)	DO NOT CUT	3/4 in. (20 mm)	1 in. (26 mm)	DO NOT CUT	
Soft Steel Bolts	9/16 in. (14 mm)	3/4 in. (20 mm)	5/8 in. (16 mm)	5/8 in. (16 mm)	7/8 in. (32 mm)	DO NOT CUT	
Standard Guy Wire	1/2 in. (14 mm)	5/8 in. (16 mm)	9/16 in. EHS (14 mm)	5/8 in. (16 mm)	3/4 in. or 20 mm	DO NOT CUT	DO NOT CUT
Telecommunication Cable						3.35 in.	540
Lead Sheath Cable						520	540
Chain	DO NOT CUT	DO NOT CUT	1/4 in.	DO NOT CUT	DO NOT CUT	DO NOT CUT	

## Hydraulic Operated Cutters

SEE BELOW

Will cut anything from guy wire to anchor rod and most overhead and under ground cables. The S-40B and S-85 feature a two stage pumping piston for rapid advance. The cutters were specifically designed to cut the toughest EHS guy wire, ground and anchor rods. The Anvil style blades eliminate jamming and are easily replaced in the field. Use S-32CC for EHS guy wire use.



### Ordering Information

Part Number	S-20	S-24	S-32	S-40B	S-55	S-85	S-32CC
Output	4.4 Ton	7.8 Ton	19.8 Ton	6.3 Ton	13 Ton	2.7 Ton	19.8 Ton
Weight	6 lbs	9 lbs	21 lbs	12 lbs	17 lbs	15 lbs	23 lbs
Length	15 in.	17 in	27 in.	23 in.	24 in.	26 in.	27 in.
Replacement Blade	20-07	24-08	32-06	40-14	55A-10	85-12	32C-06
Copper / Aluminum Wire	3/4 in. (20 mm)		1-1/4 in. (32 mm)	1-1/2 in. (40 mm)	2 in. (50 mm)	3 in. (76 mm)	DO NOT CUT
Rebar, Ground, Anchor Rod	1/2 in.(13 mm)		7/8 in. (22 mm)	5/8 in. (16 mm)	3/4 in. (20 mm)	DO NOT CUT	1 in. (26 mm)
Aluminum Conductor Steel Reinforced	3/4 in. (20 mm)		1-1/4 in. (32 mm)	1-1/2 in. (40 mm)	2 in. (50 mm)	3.35 in. (85 mm)	DO NOT CUT
Wire Rope	3/4 in. or 20 mm		1-1/4 in. (32 mm)	3/4 in. (20 mm)	1 in. (26 mm)	DO NOT CUT	DO NOT CUT
Soft Steel Bolts	11/16 in. (17 mm)		1-1/4 in. (32 mm)	3/4 in. (20 mm)	1-1/4 in. (32 mm)	DO NOT CUT	1 in. (26 mm)
Standard Guy Wire	1/2 in. (14 mm)		7/8 in. (22 mm)	5/8 in. (16 mm)	3/4 in. (20 mm)	DO NOT CUT	7/8 EHS (22 mm)
Telecommunication Cable	DO NOT CUT		DO NOT CUT	DO NOT CUT	DO NOT CUT	DO NOT CUT	DO NOT CUT
Lead Sheath Cable	DO NOT CUT		DO NOT CUT	DO NOT CUT	DO NOT CUT	3.35 in. (85 mm)	DO NOT CUT
Chain	DO NOT CUT		DO NOT CUT	DO NOT CUT	DO NOT CUT	DO NOT CUT	1/2 in.