

CHAIN SAWS / CUT-OFF SAWS

Chain Saw CE Version

CS11

The CS11 hydraulic chain saw is designed for extreme duty applications underwater as well as on land. With many available bar lengths (up to a 43 inch/109 centimeter cut), the CS11 can handle tasks such as cutting wood or bridge pilings underwater. CS11 chain saw bar and chain sold separately.

Features

- Safety has been designed in with interlocking triggers, bucking spurs and hand guards on all models
- Many available bar lengths: 24, 30, and 36 in. (61, 76, 91 cm) cut
- Handles tasks such as cutting wood and bridge pilings underwater, railroad ties, and utility poles
- Kickback is reduced without the centrifugal force from the flywheel used on the CS11
- Hydraulic power doesn't require a flywheel to smooth power pulses so there is no chain coasting when trigger is released

CS113NO Includes

- 12 in. Hose Whips: Part Number 01652
- Quick Disconnect Face Coupler Set: Part Number 03971
- User Manual

Accessories	
02938	Standard Sprocket for 3/8 in. Pitch Chain
01824	24 in. /61 cm Chain
03194	30 in. /76 cm Chain
03195	36 in. /91 cm Chain
02684	24 in. /61 cm Sprocket Nose Bar
03192	30 in. /76 cm Sprocket Nose Bar
03193	36 in. /91 cm Sprocket Nose Bar

Cut-off Saws

CO23

The Stanley CO23 Cut-Off Saw is a lightweight and powerful saw which is ideal for accurate dimensional cutting of concrete, masonry, pipes, structural steel beams, and guardrail in underwater applications. Quick disconnect couplers Part Number 03971 and cutting wheel are sold separately.

Features

- Cast aluminum handle with inter-locking safety trigger
- Adjustable wheel guard
- Build-in flow control to prevent over speeding and a blade brake that retards spindle rotation
- Uses standard 10 in. (25.4 cm) diameter abrasive or wet or dry diamond blades for cutting

CO23341 Includes

- 12 in. Hose Whips: Part Number 01652
- User Manual

Accessories	
03971	Quick Disconnect Flush Face Coupler Set
03694	10 in./25.4 cm Dia., CO23 Masonry Cutting Diamond Wheel
04116	10 in./25.4 cm Dia., CO23 Masonry Cutting Abrasive Wheel Fast Cut
04117	10 in./25.4 cm Dia., CO23 Masonry Cutting Abrasive Wheel Long Wear
Service Tools	
04120	Seal Kit
34175	Handle Extension Kit
33228	Water Attachment
05044	Bearing Installation Tool



Ordering Information		
CS113NO	U/W Chain Saw CE Heavy Duty, less bar and chain, comes with hose whips and couplers	
Service Tools		
03327	Seal Kit 3 PC Part Number 03272 Motor	
03328	Repair Kit	
04337	O-ring Tool Kit	
05044	Bearing Installation Tool	
10569	Seal Kit for CS11	
Specifications		
Item	U.S.A.	METRIC
Capacity	24, 30, 36 and 43 in. cut	61, 76, 91 and 109 cm cut
Weight	14 lbs	6 kg
Length	17 in.	43 cm
Width	9 in.	23 cm
Pressure	1500-2000 PSI	105-140 bar
Flow Range	10-14 GPM	38-53 LPM
Optimum Flow	14 GPM	53 LPM
Porting	8 SAE O-Ring	
Hose Whips Included	Yes	
Connect Size and Type	3/8 in. Male Pipe Hose End	
Motor	Hyrevz™ Gear	



Ordering Information		
CO23341	Cutoff Saw Underwater, 1 in. Arbor Open-Center, less cutting wheel and couplers, with hose whips	
Specifications		
Item	U.S.A.	Metric
Output Capacity	10 in. wheel	25.4 cm
Input Flow Range	10-15 GPM	38-57 LPM
Input Pressure	1500 - 2000 PSI	105 - 140 bar
Optimum Flow	15 GPM	57 LPM
Weight	23 lbs	10.4 kg
Dimensions	19-1/2 in. L x 11 in. W	49.5 cm x 27.9 cm
Motor	HYREVZ™ Gear	
Porting	8 SAE O-Ring	
Connect Size and Type	-8 SAE Threaded Ports	