



# FLIGHT DECK™

**Choice of the U.S. Navy and Royal Australian Navy**

The **ESS Flight Deck™** is designed specifically for all-day use with cranial-style helmets. The patented **Speed Clips™** make strap adjustment quick and easy. It is the only commercial goggle authorized by the U.S. Navy for use on flight decks.

The **Flight Deck™** fits over most eyeglasses. Includes two high-impact lenses—Clear and Smoke Gray.



Pat. #6,047,410

## Lenses

- Clear & Smoke Gray 2.4mm polycarbonate high-impact lenses included (Hi-Def Yellow available)
- Lenses feature **ESS ClearZone™** anti-fog & anti-scratch lens coatings
- Lenses are highly impact resistant, and exceed the U.S. Military's .22 caliber ballistic impact test MIL-V-4351 IC
- All lenses provide 100% UVA/UVB protection & precise optical clarity for distortion-free vision
- **ESS Modular Technology™** allows all lenses to be quickly and inexpensively interchanged
- **Laser Protective Lenses (LPLs)** available for the most common laser wavelengths

## Strap System

- Patented **Speed Clip™** strap system is ideal for cranial helmets, making strap adjustment quick & easy
- 26mm-wide, high-memory elastic strap

## Frame

- Gray frame features extra-soft face padding for superior comfort and a tight, sealed fit
- Full-perimeter ventilation & filtration system allows humidity to escape while filtering out airborne particles, air blasts, & splashes
- Increased peripheral vision far superior to the **Sun, Wind & Dust** goggle
- Fits comfortably over most prescription eyewear

## Rx Insert

- Prescription lenses can be fit by any optometrist into the **Striker™ Rx Insert**, which installs inside the goggle frame

## Full compliance with the following standards & regulations:

- ANSI Z87.1-2003+
- US MIL-V-4351 IC
- US Federal OSHA standards
- CE EN 166 (B)
- US Navy Authorized

## National Stock Numbers (NSN):

- 4210 01-492-5720 #ESS01CB-NV (Flight Deck Goggle)
- 4210 01-492-5722 #EL1-50 (50 Pack of Replacement Lenses: Clear)
- 4210 01-492-5725 #EL2-50 (50 Pack of Replacement Lenses: Smoke Gray)

**High Adrenaline Eye Protection**