

AMRON

INTERNATIONAL
EVERYTHING UNDER PRESSURE™



CHAMBER LIGHT

7100 SERIES

Amron's hyperbaric chamber light
featuring LED technology



Model 7140

Looking for a high quality Amron chamber light that won't break the bank? The Amron 7140 Standard LED Hyperbaric Chamber Light offers some amazing features at a great price.

Features

- 4.2 Watt LED bulb equivalent to 30 Watt Halogen bulb
- Long lasting LED technology with a 30,000 hour life
- Adjustable integrated mounting plate
- Low heat with high-performance heat sink
- 3-pin Male Marsh Marine Connection
- Relief valve that allows the light to dive to 1000 feet (300 MSW)
- Rugged 6061 Black Hard Anodized Aluminum housing
- Optional magnetic base, red, or blue lens filter available



Model 7100 and 7120

Amron International's 7100 and 7120 Series of LED Hyperbaric Chamber Lights provides industry leading illumination along with a dimmer feature not found on competitor's LED lights. The 7100 and 7120 Series comes with an industry standard mounting plate to allow easy retrofit in existing chamber installations and an optional magnetic base that allows for quickly moving the light as needed.

The 7100 comes with a 3-pin bulkhead connector and the 7120 comes with a 4-pin bulkhead connector which allows the light dimmer to be controlled from the outside of the chamber. The dimmer is controlled by a button located on the side of the light. Should the light be turned off inside the chamber, the chamber operator can turn the light on by cycling the power to the light from the outside.



Low profile design with integrated mounting plate

Multiple mounting options available - Magnet base shown

First ever push button dimmer - Simple touch control for easy adjustment of light intensity

High-performance heatsink - Cool to the touch
Long lasting LED technology with 50,000 hour life

Available with three and four pin connections

Red and blue lens available



AMRON
INTERNATIONAL
EVERYTHING UNDER PRESSURE™