

AMRON

INTERNATIONAL



2-DIVER AIR CONTROL

8225i SERIES

Designed to meet IMCA guidelines

Amron International 2-Diver Air Control 8225i Series

Designed to meet IMCA guidelines



Pneumo System

Pneumo Gauges have a 6 in. dial, dual scale 0-250 FSW/0-76 MSW, with 1 ft. increments. The accuracy of the gauge is 0.25% of full scale. Gauges are supplied with certificates traceable to the National Institute of Standards and Technology.

Amcom II 2-Diver Radio

The Amron International Amcom™ II 2-Diver Radio is the most versatile and powerful two diver communicator on the market today. The most unique feature of the 2828A series is separate channels and volume control for each diver and the tender for both uplink and downlink paths. The volume can be set individually for each diver and tender to a level that is optimal for them.

Air Control

The 8225i series 2-Diver Air Control System features independent high and low-pressure air supplies for both divers.

Each diver channel consist of one HP channel that has a #4 JIC HP connection fitting, regulating inlet valve and HP pressure reducing regulator. Each LP channel consist of one #6 JIC connection fitting, a 0-600 PSI outlet gauge and one oxygen outlet fitting.



Amron 2-Diver Air Control 8225i Series

8225i	Amron 2-Diver Air Control
8225iC	Amron 2-Diver Air Control with Communicator

AMRON
INTERNATIONAL
EVERYTHING UNDER PRESSURE™

 **IMCA**
MEMBER

 **ADC**
INTERNATIONAL

 facebook.com/amrondiving
 twitter.com/amronintl

Amron International Inc.
1380 Aspen Way
Vista CA, 92081

Phone: 760.208.6500
Email: sales@amronintl.com
Web: amronintl.com