

Dräger Aerotest Alpha

The Dräger Aerotest Alpha is the instrument of choice for monitoring the purity of breathing air in the low pressure range. In combination with the Dräger Oil Impactor, the system achieves an unprecedented quality of breathing air monitoring.



D-6657-2009

TESTED BREATHING AIR

The Dräger Aerotest Alpha allows the quality of breathing air supplied by a compressor or compressed gas cylinder to be determined. Use of the test system performs a reliable check in accordance with the breathing air standard EN 12 021.

The Aerotest product family is based on the well-known Dräger-Tubes detection system, an efficient method of detecting and measuring toxic gases. Thus the Dräger Aerotest Alpha allows the quantitative measurement of a variety of potentially harmful substances, such as carbon monoxide, carbon dioxide, water vapor and oil, in the compressed air flow. The concentrations can be determined either individually or simultaneously.

QUICK AND EASY APPLICATION

The measuring device, which functions independently of a power source, can be

easily connected by means of a plug-in connector to the low pressure compressed air network to be checked. In just five minutes, the Quick-Check indicates measurement results and provides information about the degree of contamination.

THE DRÄGER OIL IMPACTOR

The Dräger Oil Impactor is specially designed to test compressed air for oil aerosols. For the first time, not only conventional oils but also synthetic oils – regardless of type and viscosity – can be measured easily.

ALWAYS READY FOR USE

All components of the Dräger Aerotest Alpha are housed ready for use in a handy carrying case.



D-6654-2009

Dräger Aerotest Alpha:
All the necessary components in a single system.

TECHNICAL DATA

Dräger Aerotest Alpha	
Dimensions of carrying case (L x W x H)	350 x 300 x 85 mm
Weight, including contents	approx. 3,0 kg
Max. supply pressure	15 bar
Pressure gauge	0.3 to 15 bar
Connection for compressed air supply, barbed nipple	9 mm
Supply pressure (set on delivery)	3,0 bar
Flow rate	0,2 and 4,0 l/min



Instructions for Use

Transport Case

Connecting Adapter

Measuring Device

Pressure Reducer

Dräger Oil Impactor

Dräger-Tubes

ORDER INFORMATION

Dräger Aerotest Alpha

Dräger Aerotest Alpha
 comprising of 1 pressure reducer, measuring device for 4 tubes,
 impactor adapter, coupling, barbed nipple,
 stopwatch, tube opener Dräger TO 7000, bubble test hose,
 pack of 5 sintered filters, instruction for use, transport case (black)

65 27 149

Tube Opener
 Dräger TO 7000

Dräger Aerotest Alpha, with Dräger Tubes

box of 10 Dräger Oil Impactors,
 box of 10 Dräger-Tubes carbon dioxide (CO₂) 100/a-P,
 box of 10 Dräger-Tubes carbon monoxide (CO) 5/a-P,
 box of 10 Dräger-Tubes water vapor (H₂O) 20/a-P

65 27 150

HEADQUARTERS

Dräger Safety AG & Co. KGaA
 Revalstrasse 1
 23560 Lübeck, Germany

www.draeger.com

SUBSIDIARIES

AUSTRALIA

Draeger Safety Pacific Pty. Ltd.
 Axxess Corporate Park
 Unit 99, 45 Gilby Road
 Mt. Waverley Vic 3149
 Tel +61 3 92 65 50 00
 Fax +61 3 92 65 50 95

CANADA

Draeger Safety Canada Ltd.
 7555 Danbro Crescent
 Mississauga, Ontario L5N 6P9
 Tel +1 905 821 8988
 Fax +1 905 821 2565

P. R. CHINA

Beijing Fortune Draeger Safety
 Equipment Co., Ltd.
 A22 Yu An Rd, B Area,
 Tianzhu Airport Industrial Zone,
 Shunyi District, Beijing 101300
 Tel +86 10 80 49 80 00
 Fax +86 10 80 49 80 05

FRANCE

Dräger Safety France SAS
 3c route de la Fédération,
 BP 80141
 67025 Strasbourg Cedex 5
 Tel +33 3 88 40 59 29
 Fax +33 3 88 40 76 67

ITALY

Draeger Safety Italia S.p.A
 Via Longarone 35
 20080 Zibido San Giacomo (MI),
 Italy
 Tel +39 02 90 59 49 1
 Fax +39 02 90 00 36 86

MEXICO

Draeger Safety S.A. de C.V.
 Av. Peñuelas No. 5 Bodega No. 37
 Fraccionamiento Industrial
 San Pedroto
 Querétaro, Qro México
 Tel +52 442 246-1113
 Fax +52 442 246-1114

NETHERLANDS

Dräger Safety Nederland B.V.
 Edisonstraat 53
 2700 AH Zoetermeer
 Tel +31 79 344 46 66
 Fax +31 79 344 47 90

REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd.
 P.O.Box 68601
 Bryanston 2021
 Tel +27 11 465 99 59
 Fax +27 11 465 69 53

SINGAPORE

Draeger Safety Asia Pte Ltd
 67 Ayer Rajah Crescent
 #06-03
 Singapore 139950
 Tel +65 68 72 92 88
 Fax +65 65 12 19 08

SPAIN

Dräger Safety Hispania S.A.
 Calle Xaudaró 5
 28034 Madrid
 Tel +34 91 728 34 00
 Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
 Blyth Riverside Business Park
 Blyth, Northumberland
 NE24 4RG
 Tel +44 1670 352-891
 Fax +44 1670 356-266

USA

Draeger Safety, Inc.
 101 Technology Drive
 Pittsburgh, PA 15275
 Tel +1 412 787 8383
 Fax +1 412 787 2207