

SR² REGULATOR

The SR² regulator continues the legacy the SR¹ created. It packs advanced technology into a compact case, employing contemporary styling and utilizing a multitude of cutting edge materials. Superior breathing performance of less than 0.5 joules/liter, W.O.B. at 165 fsw, 62.5 RMV. The SR² is more technically advanced and more attractive than its predecessor.



SECOND STAGE FEATURES

- One touch performance adjustment
- Pneumatically balanced second stage
- Super flex hose
- Nitrox ready up to 40%
- Large flexible purge cover
- SMART Demand Lever - relieves load on seat. Extends seat's life while in storage.
- Improved flexible purge cover
- Free Parts for Life.
(Restrictions apply)



FIRST STAGE FEATURES

- Completely dry and environmentally sealed
- Five low pressure ports on a 360° swivel
- Two high pressure ports
- Two-piece piston for precise optimum balance and intermediate pressure control
- Available in 300 BAR DIN

www.SherwoodScuba.com



**SHERWOOD
SCUBA®**