

GENERAL INFORMATION

RUBBER MOLDED AND ASSOCIATED SERIES

APPLICATIONS:

Standard, Reversed Rubber Molded Series
Applications requiring light to medium ruggedness
Hazardous environments
Field installable applications

Glass Reinforced Epoxy Series
Applications requiring medium ruggedness
Hazardous environments
Power transmission
Signal telemetry

Metal Shell Series
Applications requiring heavy ruggedness
Hazardous, rugged environments
Power transmission
Signal telemetry

CABLE:

Rubber Molded Series
Connector's power capability may be limited by amperage and voltage rating of cable to which it is molded to. With the exception of field installable connectors, the in-line series are provided on a standard 18" length of 18 AWG SO cable unless otherwise specified. The Amron Offered RMG-4-FS and RMG-4-MP are supplied with 18 Gauge SJO AIW cable for use with the Kirby Morgan Helmets.

Glass Reinforced Epoxy Series & Metal Shell Series
Connector's power capability may be limited by amperage and voltage rating of pigtails.
Customer must specify if pigtails are to be applied.

NOTE: Torque values referenced in this literature assume installation into dry metal threads. Please contact the factory for recommendations.

*DISCLAIMER NOTICE: Amron reserves the right to supply this style from multiple manufacturers.