



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way, Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.kirbymorgan.com e-mail: kmdsi@kirbymorgan.com

Bulletin #3 of 2019. June 18, 2019

CHANGE TO PRODUCT BULLETIN

P/N 510-776 Exhaust Valve Color of Material

Changed from Clear to Black

Products Affected:

205-025 Regulator Body Assembly
225-120 Rebuild Kit, Balanced Scuba Regulator
505-085 Regulator Body Assembly
505-560 SS Balanced Reg Assembly, SuperFlow 450
505-725 Tri-Valve Assembly
505-729 Tri-Valve Assembly, SL 27
505-730 Quad Valve Exhaust Assembly
505-758 350 Regulator Pod Assembly
505-776 455 Regulator Pod Assembly
525-217 Soft Goods Overhaul Kit, 57
525-218 Helmet Spares Kit, 57
525-356 Kit, Soft Goods, 37/17K/17C/57 w/455 Reg
525-358 Kit, Soft Goods Overhaul, 18/28
525-359 Kit, Soft Goods Overhaul, 27 w/455 Reg.
525-360 Kit, Soft Goods Overhaul, 17A/B
525-363 Kit, Soft Goods Overhaul, K/37/C

525-364 Soft Goods Kit, KM 97
525-365 Kit, Soft Goods Overhaul, 27
525-367 Kit, Soft Goods Overhaul 18/28 w/455 Reg
525-368 Kit, Soft Goods Overhaul, KM 47
525-370 Helmet Spares Kit, KM 97
525-377 Kit, Soft Goods Overhaul, KM 77
525-378 Helmet Spares Kit, KM 77
525-380 Kit, Soft Goods Overhaul, KM 37SS
525-381 Helmet Spares Kit, KM 37SS
525-718 Reg. Rebuild Kit, SS Balanced
525-752 Tri-Valve Exhaust Kit
525-755 Tri-Valve Exhaust Kit, SL 27
525-763 Conversion Kit, 450 Regulator For SL 27
525-764 Kit, REX Whisker Exhaust
525-767 Rebuild Kit, 455 Balanced Regulator

We will be shipping the exhaust valves P/N 510-776 in the color black as soon as our stock of the original clear valve runs out.

The material will remain the same, but the durometer has changed to decrease exhaust resistance, lowering the overall work of breathing. The black color designates the durometer change. Any old stock of the clear valves can be used without issue.



**OLD
EXHAUST VALVE
P/N 510-776**



**NEW
EXHAUST VALVE
P/N 510-776**

The previous color was clear. There will be no change in part numbers and no change in price. There will be no exchanges offered.

No change to associated procedures for maintenance of the valve are necessary

Please contact your authorized KMDSI dealer or e-mail sales@kirbymorgan.com for more information.

