



PONY MOUNT

The Highland Pony Mount is engineered to carry a small pony cylinder alongside of your primary dive cylinder. Attachment of the Pony Mount is secured underneath the 2" tank strap of your buoyancy compensator. It is designed to fit a primary cylinder with a 7.25" diameter. The pony cylinder attaches to the Highland Pony Mount with a 1" nylon strap with a stainless steel cam buckle. Available in two sizes, for both 3.2" and 4.4" diameter pony cylinders.

Easy Mounting of the Pony Cylinder

- Mount on the diver's right or left side
- Mount upright or upside-down
- Secure and stable attachment
- Easy attachment with stainless steel cam buckle
- No hose clamps



Easy Attachment to the Primary Cylinder

- Uses your BC cam strap for attachment
- Designed for 7.25" diameter primary cylinders
- Rubber bumpers to protect your cylinder's paint and finish



The band can be rotated in the bracket so that the buckle may be positioned on the left or right side

Designed for 7.25" diameter primary cylinder

HL409 - Designed for 4.4" diameter pony cylinders Aluminum 8, 13, & 19 cu ft

HL412 - Designed for 3.2" diameter pony cylinders Aluminum 6 cu ft



**NOTE: The HL412 does not have the option of rotating the band in the bracket. The buckle is in a fixed position.*