



# Dräger Panorama Nova Dive Diving Full-Face Mask

---

The Panorama Nova Dive is a full-face mask that offers various connection possibilities for regulators, underwater communication, and a low pressure warning. It allows the professional user to dive comfortably under difficult conditions.

# Benefits

## Excellent Seal

Thanks to the 5-point head harness and the double sealing surfaces on the mask body, the mask creates an excellent seal, either on the face or on a hood.

## Various Connection Possibilities

All three ports are the familiar Dräger P-Con system. The middle port is intended for the regulator, while the left and right ports are intended for communications. The diver can breathe ambient air at the surface by not plugging in the regulator, or by opening a port, until immediately before submerging, thereby saving air for the dive.

## Mechanical Low-Pressure Warning (Optional)

A port for the mechanical low-pressure warning can be found on the visor of the mask. This reliably warns the diver of low remaining air pressure.

## Additional Exhalation Valve

Should water get into the mask, it can easily be expelled through the additional exhalation valve in the mask.

## Visor

The large, flat visor offers a wide field-of-view and allows the diver to equalize pressure from the outside of the mask, using the nose pinchers.

## Quick Doffing System

Using the quick doffing system, the diver can quickly and easily remove the mask at any time.

## Four Different Versions

Open-circuit systems:

- Panorama Nova Dive Sport
- Panorama Nova Dive (with port for the mechanical low-pressure warning)

Closed-circuit systems:

- Panorama Nova Dive R (with adjustable mouthpiece for rebreathers)
- Panorama Nova Dive NM (with adjustable mouthpiece, non-magnetic, only for military users)

# Technical Data

## Weight

Panorama Nova Dive / Sport / NM / R	940 g / 2 lb 1 oz
Operating Temperature	-20 to 50 °C / -4 to 122 °F
Storage Temperature	-30 to 70 °C / -22 to 158 °F

## Exhalation Valve Opening Pressure

Panorama Nova Dive	3.2 to 6.0 mbar
Panorama Nova Dive NM/R	25 to >25 mbar

# Ordering Information

## Description

Description	Part No.
Panorama Nova Dive Sport (Without Mask Box)	T 53 700
Panorama Nova Dive	T 53 510
Panorama Nova Dive R	T 52 730
Panorama Nova Dive NM	T 16 000
T-Bit for LARV/5000/7000 Series	T 16 010
T-Bit for LAR 8000	3719156
T-Bit for LAR 8000 Back Carry	3719157
T-Bit for FGT 5400	T 16 330
Klar-Pilot Gel, 50 ml	R 52 560

Not all products, features, or services are for sale in all countries.  
Mentioned Trademarks are only registered in certain countries and not necessarily in the country  
in which this material is released. Go to [www.draeger.com/trademarks](http://www.draeger.com/trademarks) to find the current status.

**CORPORATE HEADQUARTERS**

**Drägerwerk AG & Co. KGaA**

Moislinger Allee 53-55  
23558 Lübeck

✉ [info@draeger.com](mailto:info@draeger.com)  
[www.draeger.com](http://www.draeger.com)

**USA**

**Draeger, Inc.**

7256 S. Sam Houston Parkway W.,  
Suite 100

Houston, TX 77085  
☎ 1 800 4DRAGER (1 800 437 2437)

**Canada**

**Draeger Safety Canada, Ltd.**

2425 Skymark Ave., Unit 1  
Mississauga, Ontario L4W 4Y6

☎ 1 877 DRAGER (1 877 372 4371)



Locate your Regional Sales  
Representative at:  
[www.draeger.com/contact](http://www.draeger.com/contact)