



## XT500 UNDERWEAR

For use under a dry suit in water temperatures from 10° C to 20° C

**Constructed with comfort and utility in mind, the minimalist design provides outstanding performance under all dry suits**

### KEY FEATURES & BENEFITS

- More warmth created with less bulk
- Close fit minimizes the amount of air moving around within the garment, thereby reducing the cooling effect
- Combines a fast wicking fabric with a high density inner fleece, creating a micro climate keeping the body dry and warm
- The outer layer has a water-repellent finish
- Flexible assembly of separate top, leggings and socks supplied as a complete set
- Top features thumb loops and a crotch strap to ensure the fit under the dry suit
- Leggings feature an adjustable waistband and foot loops
- Also available as a 1-piece undersuit

### Applications

- Fire & Rescue Service
- Commercial Diving
- Law Enforcement
- Military
- Recreational Diving
- Sports/Technical Diving



## PRODUCT INFORMATION

	VIKING™ XT500 UNDERWEAR
<b>Description</b>	VIKING™ XT500 is designed to be worn on its own underneath a dry suit, or on top of the XT250 for added insulation. Manufactured from high insulation, low bulk fabric, ensuring exceptional levels of protection. Even when wet, the XT500 retains a significant degree of its thermal performance, so that the diver can continue the dive in relative comfort. Available as a complete set with top, leggings and separate socks, or as a 1-piece undersuit.
<b>Design Features</b>	Top includes a crotch strap to ensure a good fit under the dry suit and thumb loops to hold the sleeves in place during donning. The thumb loops should be removed from the thumbs and pushed back under the wrist seals prior to diving. Leggings have an adjustable waistband and foot loops. Separate socks included.
<b>Temperature of Use</b>	Suitable to wear on its own under a trilaminate or rubber dry suit <b>from 10° C to 20° C</b> . When worn in conjunction with the VIKING™ XT250 underwear, the temperature range becomes <b>5° C to 15° C</b> .
<b>Material / Fabric</b>	Polyester mix with stretch, double layer. Outer layer made from: 80% Polyester / 17% Nylon / 3% Elastane Inner layer made from: 100% Polyester
<b>Weight</b>	600 g/m <sup>2</sup>
<b>Colour</b>	Black with yellow stitching
<b>Available Sizes</b>	S, M, L, XL, 2XL, 3XL
<b>Models Available</b>	<ul style="list-style-type: none"> <li>• XT500 underwear set</li> <li>• XT500 1-piece undersuit</li> </ul>
<b>Care Instructions</b>	<ul style="list-style-type: none"> <li>• Machine washable: Wash cool with half the usual amount of detergent</li> <li>• Spin and line dry</li> <li>• Do not tumble dry</li> <li>• TIP: If your machine is able to tumble on low or no heat, give your undersuit 5 minutes in the drier every few washes</li> </ul>

## VIKING™ XT500 SIZE CHART

Size	WEARER'S BODY MEASUREMENTS										
	Height		Chest Circumference		Waist Circumference		Inside Leg		Sock Size		
	cm	inch	cm	inch	cm	inch	cm	inch	EU	UK	US
S	170-178	5'7"-5'10"	86-96	34-38"	68-78	27-30.5"	79-83	31-32.5"	38-40	5-6	6-7
M	175.5-183	5'9"-6'0"	96-106	38-41.5"	78-88	30.5-34.5"	82-86	32.5-34"	41-42	7-8	8-9
L	180.5-188	5'11"-6'2"	106-116	41.5-45.5"	88-98	34.5-38.5"	85-89	33.5-35"	43-45	9-10	10-11
XL	185.5-193	6'1"-6'4"	116-126	45.5-49.5"	98-108	38.5-42.5"	88-92	34.5-36"	46	11	12
2XL	190.5-198	6'3"-6'6"	126-136	49.5-53.5"	108-118	42.5-46.5"	91-95	36-37.5"	47	12	13
3XL	195.5-203	6'5"-6'8"	136-146	53.5-57.5"	118-128	46.5-50.5"	94-98	37-38.5"	47	12	13

For additional information, visit us at [ansell.com](https://www.ansell.com) or contact us at:

**Europe, Middle East & Africa Region**  
Ansell Protective Solutions AB  
T: +46 10 205 1800  
[order.protective@ansell.com](mailto:order.protective@ansell.com)

**Latin America & Caribbean Region**  
Ansell Commercial Mexico S.A. de C.V.  
T: +52 442 248 1544 / 248 3133

**Australia**  
Ansell Limited  
T: +61 1800 337 041

**North America Region**  
Ansell Healthcare LLC  
T: +1 800 800 0444  
[info@ansell.com](mailto:info@ansell.com)

**Asia Pacific Region**  
Ansell Protective Solutions  
T: +603 8310 6688  
[order.protective@ansell.com](mailto:order.protective@ansell.com)