



HOODS

Rubber, latex and neoprene hoods for customisation of your dry suit

PRODUCT INFORMATION

	VIKING™ MAGNUM RUBBER HOOD
Key Features & Benefits	• Made from suit material to provide excellent puncture and abrasion resistance • Ideal for protection in contaminated waters • A latex neck seal is attached to the suit underneath the hood • Available in 3 sizes
Description	VIKING™ Magnum Rubber Hood is made from rubber coated fabric with a latex face seal. It is permanently attached to the suit by stitching and vulcanisation, and a latex neck seal is fitted directly to the suit underneath the hood. For optimal fit, the hood is available in 3 sizes and also has a Velcro adjustable strap at the back in order to adjust the fit of the face seal. Fitted as an option to VIKING™ PRO, PROTECH II & HD suits (Magnum Flex). Also available as a separate spare part.
Product Material	Rubber coated fabric with a latex face seal
Colour	Black
Available Sizes	M, L, XL
IMPORTANT!	MUST be used with a hood liner for thermal insulation, and to protect the ears.
	VIKING™ SURVEYOR LATEX HOOD
Key Features & Benefits	• Optional hood for all VIKING™ dry suits • Ideal for biological contaminated water diving • A latex neck seal is mounted to the suit underneath the hood
Description	VIKING™ Surveyor Latex Hood is permanently attached to the diving suit, and has a latex neck seal mounted underneath the hood. Provides a basic level of protection against biological and light contaminants. Fitted as an option to VIKING™ PRO, PROTECH II, HD, HAZTECH, VTS, WRS-D & WRS suits. Also available as a separate spare part.
Product Material	Natural rubber (NR) latex
Thickness	0.7 mm
Colour	Black
Available Sizes	Large (Standard) & Small
IMPORTANT!	MUST be used with a hood liner for thermal insulation, and to protect the ears.
	VIKING™ NAUTIC NEOPRENE HOOD
Key Features & Benefits	• Made from double lined neoprene, and with a Smoothskin face seal • A latex neck seal is mounted to the suit underneath the hood • Provides thermal protection • Available in 4 sizes
Description	VIKING™ Nautic Neoprene Hood is permanently attached to the suit and provides thermal protection. Available with or without reflective VIKING™ logotype. Made from 5 mm double lined neoprene material with a 4 mm Smoothskin face seal for a nice fit and tight seal with a full-face mask. Seams are stitched & glued on the outside. Fitted as an option to VIKING™ PRO, PROTECH II, HD, HAZTECH, VTS, WRS-D & WRS suits. Also available as a separate spare part.
Product Material	Neoprene
Thickness	5 mm (hood) / 4 mm (face seal)
Colour	Black
Available Sizes	S, M, L, XL
IMPORTANT!	Not suitable for contaminated water diving.



VIKING™ Magnum Rubber Hood



VIKING™ Surveyor Latex Hood



VIKING™ Nautic Neoprene Hood

PRODUCT INFORMATION

	VIKING™ SMOOTHSKIN NEOPRENE HOOD
Key Features & Benefits	• Smoothskin neoprene for easy cleaning of the exterior • Stretchy and comfortable • Suitable for biological contaminated water diving • A latex neck seal is attached to the suit underneath the hood
Description	A neoprene hood made from 6 mm Smoothskin neoprene with a 3 mm Smoothskin face seal which forms a seal with a full face mask. Seams are glued, stitched and taped inside. Fitted as an option to VIKING™ PRO, PROTECH II, HD, HAZTECH, VTS, WRS-D & WRS suits. Also available as a separate spare part.
Product Material	Smoothskin Neoprene
Thickness	6 mm (hood) / 3 mm (face seal)
Colour	Black
Available Sizes	S, M, L, XL
	VIKING™ SEMI DRY HOOD (NOT ATTACHED TO THE SUIT)
Key Features & Benefits	• Made from double lined neoprene & with a Smoothskin face seal • Provides thermal protection • Available in 4 sizes
Description	VIKING™ Semi Dry Hood is a separate hood i.e. a suit can be used with or without the hood. Available with or without VIKING™ logotype. Made from 5 mm double lined neoprene material with a 4 mm Smoothskin face seal for a nice fit and tight seal with a full face mask. Seams are double glued and stitched on the outside. The hood features a Velcro adjustable neck area for comfort and ease of donning & doffing.
Product Material	Neoprene
Thickness	5 mm (hood) / 4 mm (face seal)
Colour	Black
Available Sizes	S, M, L, XL
IMPORTANT!	This hood is not regarded as being water-tight.



VIKING™ Smoothskin Neoprene Hood



VIKING™ Semi Dry Hood

For additional information, visit us at [ansell.com](https://www.ansell.com) or contact us at:

Europe, Middle East & Africa Region

Ansell Protective Solutions AB
T: +46 10 205 1800
order.protective@ansell.com

Latin America & Caribbean Region

Ansell Commercial Mexico S.A. de C.V.
T: +52 442 248 1544 / 248 3133

Australia

Ansell Limited
T: +61 1800 337 041

North America Region

Ansell Healthcare LLC
T: +1 800 800 0444
info@ansell.com

Asia Pacific Region

Ansell Protective Solutions
T: +603 8310 6688
order.protective@ansell.com