



QUICK NECK SYSTEM

Flexible method of attaching a neck seal without the need for adhesives

PRODUCT INFORMATION

	VIKING™ QUICK NECK SYSTEM
Key Features & Benefits	• Flexible method of attaching a neck seal without the need for adhesives • Easy replacement reduces downtime • Facilitates in-field change of broken neck seals • Allows for multiple users on one suit, with personal neck seals • Different neck seals and sizes available
Description	The VIKING™ Quick Neck System is a modern, lightweight and flexible system that allows for quick & easy replacement of a damaged neck seal on a dry suit, without losing a day's diving. For professional teams this solves the problem of multiple people using one suit, by having their own personal neck seal and size. Fitted as an option on VIKING™ PRO, PROTECH II, HD, HAZTECH, VTS, WRS-D & WRS. Also available as a separate spare part.
Design Features	System components: • Flexible attachment platform - attached to the dry suit upon manufacturing • Neck ring - has a groove on the underside which allows for the fitting of a neck seal • Lock ring - flexible ring that holds the neck seal in place in the neck ring • Combi-tool - used for both fitting & removal of the lock ring
	VIKING™ NECK TITE NECK SEAL
Key Features & Benefits	• For use with the VIKING™ Quick Neck System • Quick change of broken seals without adhesives
Description	Latex neck seal. Standard neck seal for the VIKING™ Quick Neck System.
Product Material	Natural rubber (NR) latex
Colour	Black
Available Sizes	• SML (Small): 24 cm - 32 cm • MED (Medium): 28 cm - 37 cm • LGE (Large): 35 cm - 43 cm
	VIKING™ SILICONE NECK SEAL
Key Features & Benefits	• For use with the VIKING™ Quick Neck System • Designed principally for divers suffering from latex allergies • More comfortable to wear than traditional latex neck seals, given the elasticity of the material • Adjustable for comfort • Quick change of broken seals without adhesives
Description	Silicone neck seal. Optional neck seal for the VIKING™ Quick Neck System.
Product Material	Silicone
Colour	Black
Available Sizes	• STD (Standard): 28 cm - 37 cm / 11" - 14.5" • SML (Small): 22 cm - 30 cm / 8.6" - 11.8"
IMPORTANT!	Only for use with the VIKING™ Quick Neck System, since silicone may not be glued. Care must be taken not to split the seals, or else they will tear very easily.
	VIKING™ COMBINED LATEX HOOD & NECK SEAL
Key Features & Benefits	• For use only with the VIKING™ Quick Neck System • Ideal for biological contaminated water diving • Combination of Surveyor latex neck seal and hood • Hood/neck seal can be changed quickly without the need for adhesives
Description	This combination has been designed for use with the VIKING™ Quick Neck System to equip the diver with a method of protecting the head and provide a basic level of protection for contaminated water diving.
Product Material	Natural rubber (NR) latex
Colour	Black
Available Sizes	• MED (Medium) • LGE (Large)
IMPORTANT!	MUST be used with a thermal hood liner.



PRODUCT INFORMATION

	VIKING™ QUICK NECK WARM NECK COLLAR
Key Features & Benefits	• For use with the VIKING™ Quick Neck System • The warm neck collar is a useful addition for cold water diving • 3 mm neoprene construction • Adjustable with Velcro on both sides
Description	Short neoprene warm neck collar, for use with the VIKING™ Quick Neck System. This is a useful addition for cold water diving. The neck and head areas may be subject to significant body heat loss which a warm neck collar can help alleviate. The warm neck collar is attached to the suit by way of glue and tape, and may be fitted over all Quick Neck combinations.
Product Material	Neoprene construction
Thickness	3 mm
Colour	Black
Available Sizes	One size adjustable



For additional information, visit us at [ansell.com](https://www.ansell.com) or contact us at:

Europe, Middle East & Africa Region
Ansell Protective Solutions AB
T: +46 10 205 1800
order.protective@ansell.com

North America Region
Ansell Healthcare LLC
T: +1 800 800 0444
info@ansell.com

Latin America & Caribbean Region
Ansell Commercial Mexico S.A. de C.V.
T: +52 442 248 1544 / 248 3133

Asia Pacific Region
Ansell Protective Solutions
T: +603 8310 6688
order.protective@ansell.com

Australia
Ansell Limited
T: +61 1800 337 041

