



GLOVE RING SYSTEMS

Optional ways to attach cuffs and gloves to your VIKING™ dry suit

PRODUCT INFORMATION

	VIKING™ BAYONET RING SYSTEM
Key Features & Benefits	• Quick and easy to use system • Allows for changing of cuffs and gloves without glue • For use also with Silicone Cuffs • Includes a variety of inner rings for different thicknesses of cuffs and gloves
Description	Quick connect system for easy attachment & replacement of latex & silicone cuffs and latex gloves. May be permanently attached to the sleeve end, mounted to an existing cuff or mounted to the VIKING™ Rubber Cuff Rings. Supplied as a complete kit including all necessary parts such as VIKING™ Bellows Latex Cuffs, fitting rings, latex gloves and merino wool glove liners. Option for all VIKING™ dry suits.
Product Material	Injection moulded polyblend
Available Sizes	M, L
	VIKING™ RUBBER CUFF RINGS
Key Features & Benefits	• Easy to mount on a dry suit • Ideal for contaminated water diving as part of a sealed system • Allows for changing of cuffs and gloves without glue • For use also with Silicone Cuffs
Description	VIKING™ Rubber Cuff Rings are easy to mount and simple to use, for attaching and replacing latex & silicone cuffs as well as latex gloves. The VIKING™ Rubber Cuff Rings consist of an outer rubber ring, which is attached to the suit, and an inner plastic ring, where the cuff/glove is mounted. The outer rubber ring can be permanently attached to the sleeve by gluing & taping, alternatively mounted to an existing latex cuff. Option for all VIKING™ dry suits.
Product Material	Standard VIKING™ rubber coated material
Colour	Black
Available Sizes	Unisize
	VIKING™ SILICONE CUFFS
Key Features & Benefits	• Only for use with VIKING™ Bayonet Ring System or VIKING™ Rubber Cuff Rings • Suitable for divers with latex allergy • UV and ozone resistant • Great comfort due to the high elasticity of the material
Description	VIKING™ Silicone Cuffs can only be used with the VIKING™ Rubber Cuff Rings or the VIKING™ Bayonet Ring System, since silicone cannot be glued. Short, tapered design with cutting rings for ultimate size adjustment.
Product Material	Silicone rubber
Colour	Black
Available Sizes	Large (Standard): 13.2-17 cm / 5.2"-6.9" Small: 10.6-15 cm / 4.2"-5.9"
IMPORTANT!	Only for use with Bayonet Ring System or Rubber Cuff Rings, since silicone may not be glued. Care must be taken when using these cuffs, as they may tear quite easily.



For additional information, visit us at [ansell.com](https://www.ansell.com) or contact us at:

Europe, Middle East & Africa Region

Ansell Protective Solutions AB
T: +46 10 205 1800
order.protective@ansell.com

Latin America & Caribbean Region

Ansell Commercial Mexico S.A. de C.V.
T: +52 442 248 1544 / 248 3133

Australia

Ansell Limited
T: +61 1800 337 041

North America Region

Ansell Healthcare LLC
T: +1 800 800 0444
info@ansell.com

Asia Pacific Region

Ansell Protective Solutions
T: +603 8310 6688
order.protective@ansell.com

[WWW.ANSELL.COM](https://www.ansell.com)

Ansell, * and ™ are trademarks owned by Ansell Limited or one of its affiliates. US Patented and US and non-US Patents Pending:
www.ansell.com/patentmarking © 2024 Ansell Limited. All Rights Reserved.
Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of gloves for a specific application.

Ansell