



FlexiFit head straps ensure even distribution of pressure

Cascade-shaped nose bridge ensures fewer pressure points

Compact, low-profile design allows optimal field of view

Criss-cross straps ensure secure fit

The bayonet connector makes it easy to attach filters

Skin-friendly materials prevent skin irritation

Easy to don and doff with the Drop-Down strap design (X-plore® 3500)

Easy exhalation due to the large exhalation valve

X-plore® 3500 is pictured

# Dräger X-plore® 3500/3300 Half Mask

A perfect combination: modern design and light weight offer you extra protection and comfort. Choose the Dräger X-plore® 3500 premium mask for long lasting protection or the low maintenance, cost-effective protection of the X-plore® 3300.

**Dräger**

Technology for Life

# Benefits

## Twin-filter half-face mask

- Dräger specific bayonet connection (twin-filter system)
- mask body made from DrägerFlex material (X-plore® 3500) or Soft-TPE (X-plore® 3300)
- to be used with X-plore Bayonet filters

## Comfortable: easy respiration with low resistance

The innovative design of the respiratory protection masks ensures easy, comfortable breathing. A large opening on the exhalation valve keeps resistance low. The cascade-shaped nose bridge offers optimal distribution of pressure. The material of the masks also makes them comfortable to wear: the X-plore 3500 mask is particularly soft and skin-friendly because it is made of DrägerFlex material. Superior comfort is combined with exceptional durability.

## Well-fitting: optimal fit for any face

The positioning of the filters and the flat design of the masks provide maximum field of view and a secure fit, even when worn with a protective visor. The Dräger FlexiFit head straps provide additional comfort. Thanks to the soft materials and ergonomic shape, the mask is a perfect fit for nearly any wearer. Even under a helmet, the head strap is easily fitted. Its innovative design makes it easy to don and doff without getting tangled in the wearer's hair. The special mask straps with their criss-cross pattern are simple to adjust, ensuring optimal distribution of weight and pressure, so the mask is even more comfortable. Plus, there are three sizes to choose from (S, M, L) to ensure an optimal fit.

## Safe: innovative product features ensure optimal safety

Dräger half masks are valued for their precision design which offers optimal protection. For example, the cascade shape of the valve creates an extra powerful seal. The specially designed, flexible nose bridge ensures an extra secure fit that contours perfectly to the face, even when worn with protective eyewear. The Dräger X-plore 3500 and 3300 are equipped with two bayonet connectors on the sides for combination with the extensive Dräger X-plore bayonet filter series. These also provide a high level of safety: both filters are quick and easy to attach.

## Simple: improved product design for easy handling

Both masks are made of as few parts as possible. The advantage of this is fast, easy cleaning. No special training is required, either to use the respiratory protection masks or to (dis)assemble them. The Dräger X-plore 3500 also features a drop-down strap design. Thanks to this, the mask can be removed simply by releasing the fastener at the neck (without having to remove the helmet first, for example). When the mask is in the standby position, its inner side remains aligned with the body, protecting it from soiling.

## System Components



D-6481-2021

### Dräger X-plore® 3300 Half Mask

The economical and low-maintenance design of The X-plore® 3300 makes it a solid choice for short duration projects. This mask incorporates many features of the Premium X-plore® 3500 and is produced with a Soft-TPE mask body.



D-2361-2021

### Dräger X-plore® Bayonet Filters

Experience a new dimension of comfort and safety in respiratory protection: the Dräger X-plore® Twinfilter series. It sets the benchmark in comfort and use. The Dräger X-plore® bayonet filter series offers an extensive range of particle, gas & vapor, and combination filters.

## Technical Data

Mask body	Dräger X-plore® 3500: "DrägerFlex" material, black color. Dräger X-plore® 3300 Soft-TPE material, translucent grey color
Sizes	small (S), medium (M), large (L)
Weight	approx. 3.351 oz / 95 g
Approvals	NIOSH approval

## Ordering Information

Dräger X-plore® 3500 Premium Half Mask	size S	R55351
	size M	R55350
	size L	R55352
Dräger X-plore® 3300 Economy Half Mask	size S	R55331
	size M	R55330
	size L	R55332

## Accessories

Cleaning Wipes Alcohol Free (box of 100)	4053845
Storage Bag, Blue with Draw String	4055785

## Bayonet Filters

See separate product information sheet: Dräger X-plore® Bayonet Filters

Not all products, features, or services are for sale in all countries. Mentioned Trademarks are only registered in certain countries and not necessarily in the country in which this material is released. Go to [www.draeger.com/trademarks](http://www.draeger.com/trademarks) to find the current status.

### Corporate Headquarters

Drägerwerk AG & Co. KGaA  
Moislinger Allee 53–55  
23558 Lübeck, Germany

[www.draeger.com](http://www.draeger.com)

### USA

Draeger, Inc.  
7256 S. Sam Houston Parkway W.,  
Suite 100  
Houston, TX 77085  
☎ 1 800 4DRAGER  
(1 800 437 2437)

### Canada

Draeger Safety Canada, Ltd.  
2425 Skymark Ave., Unit 1  
Mississauga, Ontario L4W 4Y6  
☎ 1 877 DRAGER1  
(1 877 372 4371)



Locate your Regional Sales  
Representative at:  
[www.draeger.com/contact](http://www.draeger.com/contact)