

STANLEY®



HP12 POWER UNIT

The HP12 hydraulic power unit is engineered for continuous professional use and is optimized to deliver ideal flows and pressures to both Type 2 and Type 3 hydraulic tools. Its powerful 23 HP Briggs & Stratton engine and best-in-class cooling system deliver the power and heat rejection pros need to keep tools working uninterrupted all day in all types of conditions. The HP12 features an intuitive throttle selector which makes changing flow rates very easy. Its feature-rich, dependable operation make the HP12 the industry choice for high-flow applications.

HP12 POWER UNIT

FEATURES

- Type II or Type III hydraulic circuit with superior cooling
- Manually controlled engine speed provides 8 or 12 GPM
- Tool circuit lockout during startup - safety feature
- Quartz hour meter on control panel records engine run time
- Lift & Latch handle with fold-up side handles
- 35-AH sealed, non-spillable, no maintenance battery located in covered compartment
- In tank hydraulic filter with dipstick and easy access filter replacement

SPECIFICATIONS

OUTPUT CAPACITY	8-12 GPM / 30-45 LPM
PRESSURE	2000 PSI / 140 BAR
CIRCUIT TYPE	OPEN CENTER
HYDRAULIC RESERVOIR CAPACITY	3 GALLONS / 11.4 LITERS
COUPLERS	HTMA FLUSH FACE
FUEL TANK CAPACITY	5.5 GALLONS / 20.8 LITERS
ENGINE	BRIGGS & STRATTON 23 HP VANGUARD OHV
WEIGHT	340 LBS / 154 KG
LENGTH	35 IN. / 89 CM
WIDTH	21.5 IN. / 54.6 CM
HEIGHT	29 IN. / 74 CM

ORDER INFORMATION

PART NO.	DESCRIPTION
HP12B	12 GPM BRIGGS & STRATTON, 23 HP POWER UNIT

ACCESSORIES

PART NO.	DESCRIPTION
31848	DUAL HOSE, 50 FT X 1/2 IN. WITH COUPLERS
31972	DUAL HOSE, 25 FT X 1/2 IN. WITH COUPLERS
58633	TWINNED HOSE, 25 FT X 1/2 IN. WITH COUPLERS
58634	TWINNED HOSE, 50 FT X 1/2 IN. WITH COUPLERS
13360	HOSE BASKET KIT
33212	WEATHER COVER