

TP03 TRASH PUMP

FEATURES

The TP03's efficient design places the urethane impeller above material flow, reducing blockage, jamming, and overall pump water while keeping liquids moving fast enough to pump high volumes of solids at a much higher head than non-submersible pumps.

- Lightweight and durable urethane bowl and impeller
- Submersible, no priming required
- Able to run dry without damage
- Lifting eye
- HTMA quick disconnect couplers
- 3 inch discharge

SPECIFICATIONS

CAPACITY	3 IN. DISCHARGE
PERFORMANCE	450 GPM / 1688 LPM
FLOW RANGE	7 - 10 GPM / 26 - 34 LPM
PRESSURE	2000 PSI / 140 BAR
PORTS	-12 AND -14 SAE O-RING
WEIGHT	31 LBS /14 KG
LENGTH	14 IN. / 35.5 CM
CONNECTION	HTMA FLUSH FACE COUPLERS
DISCHARGE CONNECTION	3 IN. FEMALE PIPE THREAD
HOSE WHIPS	NO

ORDER INFORMATION

PART NO.	DESCRIPTION
TP0300301	3 IN. CAPACITY, URETHANE BOWL, CE

ACCESSORIES

PART NO.	DESCRIPTION
52720	COUPLER, 3 IN. MALE NPT/3 IN. MALE CAMLOCK
31972	CARRYING HANDLE
58633	QUICK LINK CONNECTOR