

STANLEY®



BR45 HYDRAULIC BREAKER

Nothing equals the impact force of hydraulic breakers. With the best power-to-weight ratio, higher blow energy, and lower noise level than pneumatic breakers, STANLEY® hydraulic breakers are simply the best choice. Our 70-lb. class breakers deliver roughly the same impact energy as most 90-lb. pneumatic breakers. Internal components are continually bathed in hydraulic oil, providing long tool life with minimal maintenance. Since the hydraulic system is totally enclosed, there is no tool exhaust or oil atomization.

BR45 HYDRAULIC BREAKER

SPECIFICATIONS

	T HANDLE	ANTI-VIBRATION HANDLE
OUTPUT	0 - 1525 BLOWS PER MINUTE	0 - 1525 BLOWS PER MINUTE
INPUT FLOW RANGE	7 - 9 GPM / 26 - 34 LPM	7 - 9 GPM / 26 - 34 LPM
INPUT PRESSURE	1500 - 2000 PSI / 105 - 140 BAR	1500 - 2000 PSI / 105 - 140 BAR
MAX. BACK PRESSURE	250 PSI / 17 BAR	250 PSI / 17 BAR
OPTIMUM FLOW	8 GPM / 30 LPM	8 GPM / 30 LPM
PORTING	-8 SAE O-RING	-8 SAE O-RING
CONNECTOR	3/8IN. MALE PIPE HEAD HOSE END	3/8IN. MALE PIPE HEAD HOSE END
STEEL CAPACITY	4-1/4 X 1 IN. HEX*, 6 X 1-1/8 IN. HEX AND 6 X 1-1/4 IN. HEX	6 X 1-1/8 IN. HEX AND 6 X 1-1/4 IN. HEX
WEIGHT	45 OR 51 LBS / 20 OR 23 KG	55 LBS / 25 KG
LENGTH	25 IN. / 65 CM	28 IN. / 72 CM
WIDTH WITH HANDLES	14 OR 17.5 IN. / 34 OR 45 CM	17.5 IN. / 45 CM

ORDER INFORMATION

PART NO.	DESCRIPTION
BR45110	BR45 T-HANDLE BREAKER, 7/8 IN. HEX
BR45120	BR45 T-HANDLE BREAKER, 1-1/8 IN. HEX
BR45120E	BR45 T-HANDLE BREAKER, 1-1/8 IN. HEX, EASI-RIDE™ FOOT
BR45125S	BR45S ANTI-VIBRATION HANDLE BREAKER, 1-1/8 IN. HEX, EASI-RIDE™ FOOT
BR45130	BR45 T-HANDLE BREAKER, 1-1/4 IN. HEX
BR45130E	BR45 T-HANDLE, 1-1/4 IN. HEX, EASI-RIDE™ FOOT
BR45135S	BR45S ANTI-VIBRATION HANDLE BREAKER, 1-1/4 IN. HEX
BR45150	BR45 T-HANDLE BREAKER, 1 IN. HEX
BR45350	BR45 UNDERWATER T-HANDLE BREAKER, 1 IN. HEX, CE
BR45550	BR45 T-HANDLE BREAKER, 1 IN. HEX

ACCESSORIES

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	
02328	CLAY SPADE, 16 IN. U/C	02334	CHISEL, 3 IN. / 76 MM BLADE X 14 IN. / 35.6 CM*	
02330	3 IN. CHISEL, 14 IN. U/C	03990	CHISEL POINT, 14 IN. / 35.6 CM	
7/8 in. Hex x 3-1/4 in. Shank	02339	1 IN. CHISEL, 14 IN. U/C	04176	GROUND ROD DRIVER, 1 IN. / 25 MM ROD
	02341	ASPHALT CUTTER, 5 IN. BLADE X 11 IN. U/C	08106	ASPHALT WEDGE, 12 IN. / 30.5 CM
	04401	MOIL POINT, 18 IN. U/C	02335	ASPHALT CUTTER, 5 IN. / 12.7 CM BLADE X 11 IN. / 28 CM*
	04961	MOIL POINT, 14 IN. U/C	02336	MOIL POINT, 14 IN. / 35.6 CM*
	05255	ROD DRIVER, 3/4 IN.	02337	CHISEL, 3 IN. / 76 MM BLADE X 14 IN. / 35.6 CM
07702	MOIL POINT, 14 IN. / 35.6 CM	02338	"HEAVY DUTY CHISEL, 1 IN. / 25 MM X 14 IN. / 35.6 CM"	
1 in. Hex x 4-1/4 in. Shank	07703	NARROW CHISEL, 14 IN. / 35.6 CM	04367	GROUND ROD DRIVER, 1 IN. / 25 MM ROD
	07704	CHISEL, 3 IN. / 76 MM BLADE X 14 IN. / 35.6 CM	04404	HEAVY DUTY MOIL POINT, 18 IN. / 45.7 CM
	07705	CLAY SPADE, 5-1/2 IN. / 14 CM BLADE	08119	ASPHALT WEDGE
	07706	ASPHALT WEDGE, 3 IN. / 76 MM BLADE	04405	CLAY SPADE, 8 IN. / 20.3 CM BLADE
02331	CLAY SPADE, 5-1/2 IN. / 14 CM BLADE	09262	CLAY SPADE, 5-1/2 IN. / 14 CM	
1-1/8 in. Hex x 6 in. Shank	02332	ASPHALT CUTTER, 5 IN. / 12.7 CM BLADE X 11 IN. / 28 CM	17782	DETACHABLE SHANK
	02333	MOIL POINT, 14 IN. / 25.6 CM		

STANLEY

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // www.IndustrialToolsAndAttachments.com