

TACTICAL SIDE POUCH INFLATABLE LIFE PRESERVER (MD1250 / MD1250 SO)



MUSTANG SURVIVAL WE SAVE LIVES FOR A LIVING

The low profile MD1250 provides flotation capability with minimum bulk or interference using separate, independently operated left and right side pouches. With the option to wear on a standard or padded LE belt or attach directly to Pouch Attachment Ladder System (PALS) webbing on Modular Lightweight Load-carrying Equipment (MOLLE) vests, the MD1250 is a versatile solution for users who require emergency flotation with minimal bulk or interference with gear.

Using Hydrostatic Inflator Technology, each pouch will automatically inflate when submerged in 4 or more inches of water but not inadvertently due to rain, spray or humidity. The stabilization cap, patent pending, protects the inflator from impact damage that may be seen during a mission. When fitted with the included manual conversion cap, the automatic hydrostatic function can be disabled only allowing manual activation by pulling the beaded handle. This is designed so that the user can set the MD1250 for manual inflation for aviation transport and quickly convert to automatic inflation for maritime operations.



The included manual conversion cap can be installed over the inflator's water inlet port to prevent automatic operation

Will not inflate prematurely due to rain, humidity or wind-driven sea spray

A unique dual strap system allows the MD1250 to be quickly attached to standard or padded Law Enforcement belts up to 3" wide or integrated with a MOLLE style vest, body armor and most other tactical vests

SecureZIP™ closure withstands rigorous activity and is easy to repack.

No inflator maintenance is required for five years, unless inflated

Beaded manual inflation handle

Each unit (left and right) provides 35 lb buoyancy for 70 lb total buoyancy. This high level of buoyancy helps offset the weight of equipment.

A nylon webbing strap with Velcro® attachments located on the front of the bladders allows the wearer to connect the front lobes of the life preserver, once inflated, to better support the wearer in the water. (Not shown)

SOLAS retro-reflective tape not shown.

*California residents please refer to:
mustangs survival.com/pages/proposition-65

SIZE	UNIVERSAL ADULT
COLOR	MD1250 ■ BLACK ■ COYOTE TAN BLADDER: YELLOW WITH SOLAS TAPE MD1250 SO ■ BLACK ■ COYOTE TAN BLADDER: OLIVE DRAB WITHOUT SOLAS TAPE
RE-ARM KIT	(2X) MA7214-10 MA7224 TRAINING RE-ARM KIT: LOWER COST, MANUAL ONLY INFLATION FOR FAMILIARIZATION AND SAFETY TRAINING (PACK OF 12)