

STANLEY®



HP28 POWER UNIT

The HP28 (TWIN8) twin circuit hydraulic power unit offers a revolutionary design capable of operating two tools at 8 gpm simultaneously. For the first time running two hydraulic tools at full 8 gpm capacity is a reality, increasing productivity and versatility like never before. Experience how the HP28 will change the way hydraulic tools are used and JOIN THE REVOLUTION! Each of the two circuits is optimized to deliver ideal flows and pressures to both Type 1 and Type 2 hydraulic tools.

HP28 POWER UNIT

FEATURES

- ATM Technology: Active Thermal Management (ATM) optimizes performance in extreme weather conditions. By managing oil temperatures, preheat time is decreased and tool runtime increases
- Side Handles: New side handles improve ease of lifting the unit while adding side impact protection and with no moving parts to wear or corrode
- Solid Tires: Eliminates the need to refill flat tires and decreases pull force needed for maneuvering
- Tough Grip Multi Position Handle: Special Tough Grip handle surface improves comfort and control with increased durability
- Recessed Control Panel Protects dashboard and couplers
- Lifting Hook - Flush face design protects the lifting hook from accidental job abuse
- The Dual Circuit unit can operate two tools simultaneously

SPECIFICATIONS

OUTPUT CAPACITY	2 EACH 5 OR 8 GPM / 20 OR 30 LPM
PRESSURE	2000 PSI / 140 BAR
CIRCUIT TYPE	OPEN CENTER
HYDRAULIC RESERVOIR CAPACITY	3.2 GALLONS / 12.1 LITERS
COUPLERS	HTMA FLUSH FACE
FUEL TANK CAPACITY	4.7 GALLONS / 17.8 LITERS
ENGINE	BRIGGS & STRATTON 27 HP VANGUARD OHV
WEIGHT	360 LBS / 163 KG
LENGTH	37.5 IN. / 95.25 CM
WIDTH	25.75 IN. / 65.4 CM
HEIGHT	30 IN. / 76.2 CM
HEAT REJECTION	9 HP

ORDER INFORMATION

PART NO.	DESCRIPTION
HP28B02	5 OR 8 GPM BRIGGS & STRATTON 27 HP
HP28B13	5 OR 8 GPM BRIGGS & STRATTON 27 HP, INTERNATIONAL

ACCESSORIES

PART NO.	DESCRIPTION
31848	DUAL HOSE, 50 FT X 1/2 IN. WITH COUPLERS
31972	DUAL HOSE, 25 FT X 1/2 IN. WITH COUPLERS
58633	TWINNED HOSE, 25 FT X 1/2 IN. WITH COUPLERS
58634	TWINNED HOSE, 50 FT X 1/2 IN. WITH COUPLERS