

# STANLEY®



## SK58 SINKER DRILL

The STANLEY® SK58 Sinker Drills are powerful hydraulic tools designed for blast hole drilling, gas leak detection, and dowel hole applications. Depending on the model, they use air or water flushing to clear debris and feature a feathering trigger for precise starts with adjustable speeds up to 300 RPM. The SK47 can drill holes up to 2 inches in diameter and 10 feet deep, while the SK58 handles holes up to 3 inches in diameter and 20 feet deep, making them ideal for heavy-duty utility and construction work.

# SK58 SINKER DRILL

## FEATURES

- The STANLEY® SK58 Sinker Drill is designed for heavy-duty utility construction, blast hole drilling, leak detection for gas utilities, dowel drilling. A model is available for underwater use.
- The rotation is independent of impact rate and is adjustable between 0 and 300 rpm. The sinker drill can drill up to a 3 in. (75 mm) diameter hole up to 20 ft (6 m) deep.
- The Sinker Drill features an easy start feathering trigger and a direct drive rotation motor for reliable service and fast and easy starting
- Models are available with air or water flushing to clear holes of debris

## SPECIFICATIONS

|                             |                                    |
|-----------------------------|------------------------------------|
| CAPACITY (SK58130)          | 7/8 IN. HEX X 4-1/4 IN. SHANK      |
| CAPACITY (ALL OTHER MODELS) | 1 IN. HEX X 4-1/4 IN. SHANK        |
| PERFORMANCE                 | 3 IN. X 20 FT. DEEP HOLE           |
| FLOW RANGE                  | 7 - 9 GPM / 26 - 34 LPM            |
| PRESSURE                    | 1500 - 2000 PSI / 105 - 140 BAR    |
| PORTS*                      | -8 SAE O-RING (H), 1/2 IN. NPT (A) |
| WEIGHT                      | 67 LBS / 30 KG                     |
| LENGTH                      | 26 IN. / 66 CM                     |
| WIDTH                       | 18 IN. / 46 CM                     |
| CONNECTION                  | 3/8 IN. MALE NPT PIPE ADAPTER      |
| HOSE WHIPS                  | YES                                |
| MOTOR                       | INTEGRAL                           |

\* (H) = HYDRAULIC (A) = AIR

## ORDER INFORMATION

| PART NO. | DESCRIPTION                               |
|----------|---|
| SK58110  | AIR, FLUSH OPEN CENTER SYSTEM             |
| SK58120  | WATER, FLUSH OPEN CENTER SYSTEM           |
| SK58130  | AIR, FLUSH OPEN CENTER SYSTEM             |
| SK58310  | UNDERWATER, AIR, FLUSH OPEN CENTER SYSTEM |

## ACCESSORIES

| PART NO.  | DESCRIPTION                                    |
|---|--|
| <b>CARBIDE ROCK BITS SHOULDER DESIGN FOR USE WITH AIR</b> |  |
| 05177   | 1-3/8 IN. DIAMETER, HEX THREAD                 |
| 05178   | 1-1/2 IN. DIAMETER, HEX THREAD                 |
| <b>DRILL STEELS FOR USE WITH AIR</b>                      |  |
| 04915   | 1 IN. HEX X 4-1/4 IN., HEX THREAD 36 IN. U/C   |
| 05170   | 1 IN. HEX X 4-1/4 IN., HEX THREAD 24 IN. U/C   |
| 05171   | 1 IN. HEX X 4-1/4 IN., HEX THREAD 48 IN. U/C   |
| 05174   | 7/8 IN. HEX X 4-1/4 IN., HEX THREAD 24 IN. U/C |

**STANLEY**®

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // [www.IndustrialToolsAndAttachments.com](http://www.IndustrialToolsAndAttachments.com)

2025.08.07