

STANLEY®



IW12 IMPACT WRENCH

The STANLEY® IW12 Hydraulic Impact Wrench is a powerful and versatile tool engineered for demanding tasks, such as bolt loosening, drilling, and bolt driving, suitable for use in both dry and underwater applications. Powered by a Hyrevz™ motor, it delivers adjustable impact torque from 250 to 1,200 ft-lbs, making it suitable for various tasks in harsh environments. With a 3/4-inch square drive, feathering trigger for smooth operation, and an ergonomic handle for comfort, the IW12 minimizes operator fatigue. Its rugged design allows for use at depths of up to 1,000 feet, making it ideal for commercial diving operations. The wrench's adjustable intensity and reversing valve provide excellent control, ensuring reliable performance in a wide range of applications.

IW12 IMPACT WRENCH

FEATURES

- The IW12 impact wrench features adjustable impact intensity. The IW12 can handle a wide variety of applications.
- The rugged STANLEY impact wrench mechanism is simple to maintain and has many features to give it proven reliability. Torque transmission to the operator is minimal with the swing hammer design.
- The larger feathering trigger is convenient to use and gives the operator complete control of the wrench. The standard reversing valve provides instant reverse.
- For operator comfort the IW12 handle is coated with a heat insulating, shock absorbing material.

SPECIFICATIONS

CHUCK TYPE-SQ. DRIVE	0.75 IN. / 1.9 CM
TORQUE	250 - 1200 FT LBS / 340 - 1632 NM
INPUT PRESSURE	1000 - 2000 PSI / 70 -140 BAR
WEIGHT	14 LBS / 6.4 KG
LENGTH	9.5 IN. / 24.1 CM
WIDTH	4 IN. / 10.2 CM
CONNECTION	ISO 16028 FLAT FACE COUPLER - SIZE 8
MOTOR	INTEGRAL
HOSE WHIPS	NO
FLOW RANGE	4 - 12 GPM / 15 - 45 LPM

ORDER INFORMATION

PART NO.	DESCRIPTION
IW12140	IMPACT WRENCH, OPEN CENTER, 3/4 IN. SQUARE DRIVE
IW12140S	IMPACT WRENCH, OPEN CENTER, 3/4 IN SQUARE DRIVE, RAILROAD DEDICATED
IW1214001	IMPACT WRENCH, OPEN CENTER, 3/4 IN SQUARE DRIVE, CE
IW1234001	IMPACT WRENCH, OPEN CENTER, 3/4 IN SQUARE DRIVE, UNDERWATER, CE

ACCESSORIES

PART NO.	DESCRIPTION
01857	ADJUSTABLE CHUCK & ADAPTER – 3/4 IN SQ FEMALE x 3/4 IN
05117	ADAPTER – 7/16 IN HEX x 1/2 IN SQ MALE
05080	ADAPTER – 5/8 IN HEX x 1/2 IN SQ MALE
06790	ADAPTER – 3/4 IN SQ ANVIL TO 5/8 IN HEX
SOCKETS	CONTACT LOCAL SALES REP

STANLEY[®]

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // www.IndustrialToolsAndAttachments.com