

# STANLEY®



## MHP3 TRACHORSE

The TracHorse® is an all-terrain, self-propelled mobile hydraulic power pack that allows transportation of tools and equipment in most job site environments. Straightforward operating controls allow for maneuvering in a wide range of applications. The auxiliary hydraulic tool circuit is designed for continuous-duty applications and features the standard high-efficiency cooling found on all STANLEY® hydraulic power units.

# MHP3 TRACHORSE

## FEATURES AND BENEFITS

- The Self-Propelled Mobile Hydraulic Tool and Equipment Carrier is a versatile solution for transporting tools and equipment in various job-site environments
- Simple Operating Controls - Allows for a wide range of applications
- Two Speed Forward Track Drive - Single Low Reverse Speed
- Work Lights
- Opening Tailgate
- The Auxiliary Hydraulic Tool Circuit is specifically designed for continuous-duty applications and comes equipped with the standard high-efficiency cooling system featured on all STANLEY™ hydraulic power units
- Climbs 60% grade
- Carries 1000 lbs / 454 kg

## SPECIFICATIONS

LOAD CAPACITY	1000 LBS / 454 KG
PRESSURE	2000 PSI / 38 BAR
FLOW RANGE	2 @ 5 GPM or 1 @ 10 GPM / 2-20 LPM OR 1-38 LPM
TRAVEL SPEED	1.55 MPH - 2.8 MPH / 2.5KM/H - 4.5 KM/H
HYDRAULIC RESERVOIR CAPACITY	3 GALLONS / 11 LITERS
FUEL TANK CAPACITY	7 GALLONS / 26.5 LITERS
WEIGHT (STANDARD TRACHORSE)	1200 LBS / 544 KG
LENGTH	78 IN. / 198 CM
WIDTH	36 IN. / 92 CM
HEIGHT	43 IN. / 109 CM
ENGINES	HONDA 20 HP OHV
CONNECTOR	FLUSH-FACE COUPLERS

## ORDER INFORMATION

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
MHP32242100	TRACHORSE DUAL CIRCUIT, HONDA	MHP32242100U	TRACHORSE DUAL CIRCUIT, HONDA - UPRR
MHP32232100	TRACHORSE DUAL CIRCUIT, HONDA, BEDLESS	MHP3224212	TRACHORSE DUAL CIRCUIT, HONDA - HOSE REEL

## ACCESSORIES

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
31848	DUAL HOSE, 50 FT X 1/2 IN. W/COUPLERS	35907	HOSE REEL ATTACHMENT KIT
31972	DUAL HOSE, 25 FT X 1/2 IN. W/COUPLERS	36138	HOSE REEL NO HOSE
03971	HTMA FLUSH-FACE COUPLER 3/8 IN. NPT BRUNNING	58448	HOSE ASSY, DUAL 50' W/COUPLERS
03974	HTMA FLUSH-FACE COUPLER 1/2 IN. NPT BRUNNING	58451	HOSE ASSY, DUAL 25' W/COUPLERS
47438	HTMA FLUSH-FACE COUPLER 3/8 IN. NPT AEROQUIP	69529	GAS HOSE REEL
47441	HTMA FLUSH-FACE COUPLER 1/2 IN. NPT AEROQUIP		

**STANLEY**®

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // [www.IndustrialToolsAndAttachments.com](http://www.IndustrialToolsAndAttachments.com)