

STANLEY®



DL07 DRILL

The DL07 is a variable speed drill with reverse capability. All models feature a dual position assist handle, dual spool for open or closed center operation, trigger guard, a reverse flow check valve preventing operation if tool is plumbed backward, and is powered by an integral Hyrevz™ motor. The DL07 is furnished with flush face quick disconnect couplers and either a 1/2-inch or 5/8-inch keyed chuck.

DL07 DRILL

FEATURES

- Instant reverse for high reliability and efficiency in all types of drilling applications.
- Dual-position Assist Handle on some models provides increased control and performance on tough drilling jobs
- The new over-sized reversing spool is protected by heavy-duty wiper seals. These wiper seals clean away dirt as the spool is moved
- Ideal for drilling holes in wood, metal and masonry

SPECIFICATIONS

CAPACITY	½ IN. CHUCK / 12 MM CHUCK
WEIGHT	6 LBS / 2.7 KG
LENGTH	9 IN. / 22.9 CM
PORTS	-8 SAE O-RING
MOTOR	STANLEY HYREVZ™ GEAR
SYSTEM TYPE	OPEN CENTER/CLOSED CENTER
MAXIMUM FLOW	12 GPM / 45 LPM
TORQUE	4 FT-LB A 500 PSI / .5 NM @ 35 BAR
	9 FT-LB A 1000 PSI / 1.2 NM @ 70 BAR
	14 FT-LB A 1500 PSI / 1.9 NM @ 105 BAR
	19 FT-LB A 2000 PSI / 2.6 NM @ 140 BAR

ORDER INFORMATION

PART NO.	DESCRIPTION
DL0755201	OC/CC, DUAL SPOOL, TRIGGER GUARD, ASSIST HANDLE 1/2" CHUCK, COUPLERS, NO HOSE WHIPS, CE
DL07552S	OC/CC, DUAL SPOOL, TRIGGER GUARD, ASSIST HANDLE, 1/2" CHUCK, RR DEDICATED, COUPLERS, HOSE WHIPS
DL07552B	OC/CC, DUAL SPOOL, TRIGGER GUARD, ASSIST HANDLE, 1/2" CHUCK, RR DEDICATED, AEROQUIP COUPLERS, HOSE WHIPS
DL07572S	OC/CC, DUAL SPOOL, TRIGGER GUARD, ASSIST HANDLE, 5/8" CHUCK, RR DEDICATED, COUPLERS, HOSE WHIPS
DL07572B	OC/CC, DUAL SPOOL, TRIGGER GUARD, ASSIST HANDLE, 5/8" CHUCK RR DEDICATED, AEROQUIP COUPLERS, HOSE WHIPS
DL07652	OC/CC, DUAL SPOOL. TRIGGER GUARD, 1/2" CHUCK, ASSIST HANDLE, HOSE WHIPS, NO COUPLERS, UNDERWATER USE
DL0765201	OC/CC, DUAL SPOOL. TRIGGER GUARD, 1/2" CHUCK, ASSIST HANDLE, NO HOSE WHIPS, NO COUPLERS, UNDERWATER USE, CE

ACCESSORIES

PART NO.	DESCRIPTION
CARBIDE TIPPED AUGERS WITH 7/16 IN. SHANK	
81501	9/16 IN. DIA, 12 IN. TWIST, 17 IN. OAL
81505	13/16 IN. DIA, 12 IN. TWIST, 17 IN. OAL
81453	13/16 IN. DIA, 15 IN. TWIST, 18 IN. OAL
81456	11/16 IN. DIA, 21 IN. TWIST, 24 IN. OAL
81459	1-1/16 IN. DIA, 21 IN. TWIST, 24 IN. OAL

OAL = OVERALL LENGTH

PART NO.	DESCRIPTION
CARBIDE TIPPED AUGERS WITH 7/16 IN. SHANK	
81463	11/16 IN. DIA, 24 IN. TWIST, 29 IN. OAL
81466	7/8 IN. DIA, 24 IN. TWIST, 29 IN. OAL
81467	15/16 IN. DIA, 24 IN. TWIST, 29 IN. OAL
81468	1 IN. DIA, 24 IN. TWIST, 29 IN. OAL
81469	1-1/16 IN. DIA, 24 IN. TWIST, 29 IN. OAL
08130	ASSIST HANDLE

STANLEY®

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // www.IndustrialToolsAndAttachments.com