

STANLEY®



BR67 HYDRAULIC BREAKER

Nothing matches the impact force of hydraulic breakers. With an exceptional power-to-weight ratio, superior blow energy, and reduced noise levels compared to pneumatic breakers, STANLEY® hydraulic breakers are the optimal choice. Our 70-lb class breakers deliver impact energy comparable to most 90-lb pneumatic breakers. The internal components are consistently bathed in hydraulic oil, ensuring long tool life with minimal maintenance. Additionally, the fully enclosed hydraulic system eliminates tool exhaust and oil atomization.

BR67 HYDRAULIC BREAKER

SPECIFICATIONS

	T HANDLE	ANTI-VIBRATION HANDLE
PART NUMBER	BR67120	BR67125 & BR67135
OUTPUT	0 - 1300 BLOWS PER MINUTE	0 - 1300 BLOWS PER MINUTE
INPUT FLOW RANGE	7 - 9 GPM / 26 - 34 LPM	7 - 9 GPM / 26 - 34 LPM
INPUT PRESSURE	1500 - 2500 PSI / 105 - 172 BAR	1500 - 2500 PSI / 105 - 172 BAR
MAX. BACK PRESSURE	250 PSI / 17 BAR	250 PSI / 17 BAR
OPTIMUM FLOW	8 GPM / 30 LPM	8 GPM / 30 LPM
PORTING	-8 SAE O-RING	-8 SAE O-RING
CONNECTOR	3/8 IN. MALE PIPE HEAD HOSE END	3/8 IN. MALE PIPE HEAD HOSE END
STEEL CAPACITY	6 X 1-1/4 IN. HEX AND 6 X 1-1/8 IN. HEX	6 X 1-1/8 IN. HEX AND 6 X 1-1/4 IN. HEX
WEIGHT	67 LBS / 30 KG	75 LBS / 34 KG
LENGTH	27 IN. / 68 CM	29 IN. / 73 CM
WIDTH WITH HANDLES	16 IN. / 41 CM	18 IN. / 46 CM

ORDER INFORMATION

PART NO.	DESCRIPTION
BR67120	BR67 T-HANDLE BREAKER, 1-1/8 IN. HEX
BR67120E	BR67 T-HANDLE BREAKER, 1-1/8 IN. HEX, EASI-RIDE™ FOOT
BR67130	BR67 T-HANDLE BREAKER, 1-1/4 IN. HEX
BR67130E	BR67 T-HANDLE BREAKER, 1-1/4 IN. HEX, EASI-RIDE™ FOOT
BR67320	BR67 UNDERWATER T-HANDLE BREAKER, 1-1/8 IN. HEX, CE
BR67125	BR67S ANTI-VIBRATION HANDLE BREAKER, 1-1/8 IN. HEX
BR67135	BR67S ANTI-VIBRATION HANDLE BREAKER, 1-1/4 IN. HEX

ACCESSORIES

PART NO.	DESCRIPTION
02331	CLAY SPADE, 5-1/2 IN. / 14 CM BLADE
02332	ASPHALT CUTTER, 5 IN. / 12.7 CM BLADE X 11 IN. / 28 CM*
02333	MOIL POINT, 14 IN. / 25.6 CM
02334	CHISEL, 3 IN. / 76 MM BLADE X 14 IN. / 35.6 CM*
03990	CHISEL POINT, 14 IN. / 35.6 CM
04176	GROUND ROD DRIVER, 1 IN. / 25 MM ROD
08106	ASPHALT WEDGE, 12 IN. / 30.5 CM
02335	ASPHALT CUTTER, 5 IN. / 12.7 CM BLADE X 11 IN. / 28 CM*
02336	MOIL POINT, 14 IN. / 35.6 CM*
02337	CHISEL, 3 IN. / 76 MM BLADE X 14 IN. / 35.6 CM
02338	HEAVY DUTY CHISEL, 1 IN. / 25 MM X 14 IN. / 35.6 CM
04367	GROUND ROD DRIVER, 1 IN. / 25 MM ROD
04404	HEAVY DUTY MOIL POINT, 18 IN. / 45.7 CM
08119	ASPHALT WEDGE
09262	CLAY SPADE, 5-1/2 IN. / 14 CM
17782	DETACHABLE SHANK

PART NO.	DESCRIPTION
SERVICE TOOLS	
04595	SEAL KIT
04908	SPLIT RING (AUTO VALVE REMOVAL)
04909	SPACER (FLOW SLEEVE INSTALL)
04910	FLOW SLEEVE REMOVAL TUBE
05508	ACCUMULATOR DISASSEMBLY TOOL
05640	ACCUMULATOR CYLINDER PULLER
TEST EQUIPMENT	
02835	ACCUMULATOR TESTER
04182	FLOW AND PRESSURE TESTER
31254	ACCUMULATOR CHARGE KITS

STANLEY®

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // www.IndustrialToolsAndAttachments.com