

STANLEY®



PD45 POST DRIVER

The STANLEY® PD45 is a high-performance, heavy-duty hydraulic post driver built for versatility and durability in the field. Capable of driving a wide range of post types—including “U” channel, round, square, and delineator posts—it offers unmatched control through a unique indexing design that helps reduce damage to the post top while improving placement accuracy. With multiple trigger options available, the PD45 series is ideal for general construction, utility, and DOT-specific applications.

The PD45130 is the go-to solution for general-purpose post driving. With a trigger integrated directly into the handle, it offers smooth, responsive control that’s easy to operate from any grip point. The full-length handle trigger is spring-loaded to the OFF position, enhancing operator safety without compromising speed or efficiency. It’s perfect for utility crews, contractors, and fencing professionals who need a reliable, versatile driver for a wide variety of post types.

PD45131 – Remote-Controlled Post Driver

Designed for enhanced operator safety and control, the PD45131 features a remote on/off valve that allows the user to operate the tool from a safe distance. This model is ideal for environments where precision placement and reduced exposure to impact zones are priorities. Whether you’re working in confined spaces or high-risk areas, the PD45131 ensures you get the job done efficiently and safely.

PD45132G – DOT-Compliant Post Driver

The PD45132G is engineered to meet strict State DOT standards, making it the ideal choice for roadside and traffic control installations. This version drives breakaway and delineator posts to within 4 inches (100 mm) of the ground, meeting compliance requirements without sacrificing power or ease of use. Built for municipal, highway, and transportation departments, the PD45132G is a rugged, purpose-built solution for critical infrastructure work.

PD45 POST DRIVER

FEATURES

- 7-9 gpm (26-34 lpm) operating flow
- Lifting eye
- ON/OFF trigger next to guide handle (model dependent)
- Hose whips
- Nitrogen charged accumulator
- Guide handles

SPECIFICATIONS

SPECIFICATIONS	
CAPACITY	REFER TO LISTING BELOW
WEIGHT (STANDARD)	65 LBS / 29.5 KG
WEIGHT (EXTENDED ANVIL)	71 LBS / 32 KG
LENGTH	30 IN. / 76 CM
WIDTH (ACROSS HANDLES)	10-1/8 IN. / 25.7 CM
PRESSURE	2000 PSI / 140 BAR
FLOW RANGE	7 - 9 GPM / 26 - 34 LPM
OPTIMUM FLOW	8 GPM / 30 LPM
PORTING	- 8 SAE O-RING
HOSE WHIPS	YES
CONNECT SIZE AND TYPE	3/8 IN. PIPE

ORDER INFORMATION

PART NO.	DESCRIPTION
PD45131	OPEN CENTER- REMOTE
PD45132	OPEN CENTER- IN-HANDLE
PD45132G*	OPEN CENTER- IN-HANDLE

* FOR STATE DOT REQUIREMENTS

"G" INDICATES EXTENDED ANVIL (DRIVES POSTS TO WITHIN 4 INCHES ABOVE GROUND LEVEL).

ACCESSORIES

THE ACCESSORIES LISTED BELOW ARE FOR USE THE PD45131 OR PD45132 ONLY. THEY CAN NOT BE USED WITH THE PD45132G, EXTENDED ANVIL MODEL.

PART NO.	DESCRIPTION
67784	ADAPTER FOR 1.75 IN. ROUND POST (T-POST)
15184	ADAPTER – 1.75 IN. SQUARE POST
15185	ADAPTER – 2 IN. ROUND PIPE
15186	ADAPTER – 2.25 IN. SQUARE POST
15187	ADAPTER – 2 IN. SQUARE POST

STANLEY[®]

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // www.IndustrialToolsAndAttachments.com

2025.08.07