

STANLEY®



GD50 GROUND ROD DRIVER

The GD50 drives ground rods with proven hard-hitting “top driving” power and frequency. With two models available, either 1/2 to 5/8 in. or 3/4 to 1 in. ground rod can be driven. A cast-in lifting eye allows the operator to suspend the driver above the rod with ease. The long side handles give the operator control during the driving process. The GD50 contains an interchangeable, deep socket anvil to fit the rod end. All hammering is against the anvil and not the rod. The GD50 is furnished with flush faced quick disconnect couplers, 8-foot hose whips, and dual-spool in-line ON/OFF valve.

GD50 GROUND ROD DRIVER

FEATURES

- The STANLEY® GD50 Ground Rod Driver is ideal for driving rods with proven, hard-hitting technology
- The lifting eye allows the operator to suspend the driver above the rod with ease
- The in-line valve in the 8-foot hose whips gives the operator On/Off control where he is standing
- Both GD50 models have driving anvils which are designed to fit the rods which helps to minimize damage to the rod ends
- Ideal for use by right-of-way crews, arborists, utilities, parks departments, grounds keepers, and forest trail maintenance crews

SPECIFICATIONS

CAPACITY (GD50132RF)	1/2 AND 5/8 IN. ROD / 12 AND 16 MM ROD
CAPACITY (GD50133RF)	3/4 AND 1 IN. ROD / 19 AND 25 MM ROD 19
FLOW RANGE	5 - 9 GPM / 19 - 34 LPM
PRESSURE	1500 - 2000 PSI. / 105 - 140 BAR
PORTS	-8 SAE STRAIGHT THREAD O-RING
SYSTEM TYPE	OPEN CENTER/CLOSED CENTER
WEIGHT	52 LBS / 24 KG
LENGTH	25.5 IN. / 64.8 MM
CONNECTION	3/8 IN. FLUSH-FACE QUICK DISCONNECT COUPLERS
HOSE WHIPS	YES

ORDER INFORMATION

PART NO.	DESCRIPTION
GD50132RF	SIDE HANDLE, 1/2 - 5/8 IN. ROD
GD50133RF	SIDE HANDLE, 3/4 - 1 IN. ROD