

# STANLEY®



## CS25/28 POLE CHAIN SAWS

The CS25 and CS28 pole chain saws are perfect for right-of-way crews, utilities, parks departments, and grounds-keepers as they are lightweight and have fiberglass poles that make them easy to handle in tight spots. These saws also come with automatic chain oiling, which guarantees long-lasting and reliable service.

The CS28 is designed for HTMA Type II circuits and has an optimal flow rate of 8 gpm / 30 lpm, while the CS25 is ideal for HTMA Type I circuits commonly found on bucket trucks, where hydraulic circuit flow is often limited to 4-6 gpm / 15-23 lpm.

The STANLEY® "Dual Spool" feature enables users to adjust the saw to operate from either open or closed-center circuits, making them more versatile.

The CS25/CS28 models also have a low kickback, .325-pitch saw chain for added safety, and the flow rating can be easily changed by replacing the gear chamber and two gears.

# CS25/28 POLE CHAIN SAWS

## FEATURES AND BENEFITS

- The proximity of the pole centerline to the bar centerline minimizes operator fatigue
- External bar oiler makes for quick and convenient adjustments
- Easy to source replacement parts
- OC/CC dual spool - match the tool hydraulics to the circuit
- Extra long bucking face/brush management
- Rim sprocket provides smoother operation, retains chain
- Guide plates keeps loose chain in place
- Improved handle ergonomics while wearing gloves
- One-piece oil tube and pole assembly for increased durability
- Increased connection strength by 15% to provide robust durability

## SPECIFICATIONS

	CS25	CS28
CUT CAPACITY	13 IN. / 33 CM	13 IN. / 33 CM
WEIGHT*	10.4 & 10.9 LB / 4.7 & 5 KG	10.4 & 10.9 LB / 4.7 & 5 KG
OVERALL LENGTH**	78 & 91 IN. / 198 & 231 CM	78 & 91 IN. / 198 & 231 CM
PRESSURE	1000-2000 PSI / 70-140 BAR	1000-2000 PSI / 70-140 BAR
FLOW RANGE	4-6 GPM / 15-23 LPM	7-9 GPM / 26-34 LPM
OPTIMUM FLOW	5 GPM / 20 LPM	8 GPM / 30 LPM
PORTING	-8 SAE	-8 SAE
CONNECT SIZE / TYPE	3/8 NPT MALE ADAPTER	3/8 NPT MALE ADAPTER

\* Weight includes bar and chain but not quick couplers.

\*\* Length includes bar and chain but not quick couplers.

## ORDER INFORMATION

MODEL NO.	DESCRIPTION
CS25811	LONG REACH 91"/231 CM, OC/CC, 4-6 GPM/15-23 LPM
CS25812	SHORT REACH 78"/198 CM, OC/CC, 4-6 GPM/15-23 LPM
CS28811	LONG REACH 91"/231 CM, OC/CC, 7-9 GPM/26-34 LPM
CS28812	SHORT REACH 78"/198 CM, OC/CC, 7-9 GPM/26-34 LPM
CS25811L11	LONG REACH 91"/231 CM, OC/CC, 4-6 GPM/15-23 LPM PORTUGUESE LABEL
CS25812L11	SHORT REACH 78"/198 CM, OC/CC, 4-6 GPM/15-23 LPM PORTUGUESE LABEL

## ACCESSORIES

PART NO.	DESCRIPTION
88685	COUPLER SET (MALE & FEMALE)
56725	HOSE WHIP, 18 IN.
05144	CHAIN / BAR GUARD
07616	SPROCKET SPLINE ADAPTER
07629	RIM SPROCKET 0.325 P
08347	13 IN (33 CM) SAW BAR
08348	SAW CHAIN FOR 13 IN (33 CM) BAR
11464	SCRENCH
11294	FLAT FILE
11298	DEPTH GAUGE
12363	FILE GUIDE WITH FILE

# STANLEY®

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // [www.stanleyinfrastructure.com](http://www.stanleyinfrastructure.com)