

STANLEY®



ID07 IMPACT DRILL

The ID07 is a powerful impact wrench that is ideal for tightening and loosening nuts, as well as driving lag bolts. Due to its impact mechanism, it can be used for drilling into tough materials like treated wood and utility poles without causing any torque reaction on the user.

ID07 IMPACT DRILL

FEATURES

- The ID07 can drive wood augers into the hardest saltcured or creosote-treated poles. Delivering impact torque of up to 500 ft. lbs.
- The ID07 has the work-site proven swing-hammer mechanism that will deliver high performance and long-term service
- The integral Stanley Hyrevz™ gear motor is manufactured to exacting standards to deliver maximum efficiency
- The wrench's reverse-check valve is designed to prevent operation when it is reverse-plumbed to the hydraulic system.
- Preventing reverse operation ensures a long operating life for the hydraulic seals
- Setting the tool for open-or closed-center operation is as simple as opening or closing a valve

SPECIFICATIONS

CAPACITY	7/16-IN QUICK CHANGE OR 1/2-IN SQUARE DRIVE
TORQUE	500 FT. LBS. / 675 NM
INPUT PRESSURE	750 - 2000 PSI / 50 - 140 BAR
WEIGHT	7.2 LBS / 3.3 KG
LENGTH	8.5 IN. / 21.6 CM
WIDTH	4.5 IN. / 11.4 CM
HEIGHT	10 IN. / 25.4 CM
PORTS	-8 SAE O-RING
MOTOR	STANLEY HYREVZ™
MAXIMUM FLOW	4 - 12 GPM / 15 - 45 LPM

ORDER INFORMATION

PART NO.	DESCRIPTION
ID07810	7/16-IN QC CHUCK, NO TRIGGER GUARD
ID0781001	7/16-IN QC CHUCK, CE, NO TRIGGER GUARD
ID07810S	7/16-IN QC CHUCK, RAILROAD, NO TRIGGER GUARD
ID07815	7/16-IN QC CHUCK, TRIGGER GUARD
ID07820	1/2-IN SQUARE DRIVE, NO TRIGGER GUARD
ID0782001	1/2-IN SQUARE DRIVE, CE, NO TRIGGER GUARD
ID07920	1/2-IN SQUARE DRIVE, UNDERWATER, NO TRIGGER GUARD

ACCESSORIES

PART NO.	DESCRIPTION
05117	ADAPTER, 7/16 MALE HEX X 1/2 MALE SQUARE
07192	ADAPTER, 1/2 FEMALE SQUARE X 5/8 HEX QC
21755	IMPACT SOCKET SET, 1/2 SQUARE DRIVE 8-POINT, DEEP SOCKETS. INCLUDES VINYL HOLDER AND 9 SOCKETS - 1/2, 9/16, 5/8, 11/16, 3/4, 13/16, 7/8, 1, & 1-1/16
33155	LINEMAN'S SOCKET, 13/16 AND 15/16
33156	LINEMAN'S SOCKET, 1 AND 1-1/8

