

STANLEY®



ID07 UNDERWATER IMPACT DRILL

The STANLEY® ID07 Impact Drill is a versatile hydraulic underwater tool that combines an impact wrench and wood drill in one unit. The ½" square drive impact wrench provides up to 500 ft-lbs of torque, allowing you to tighten and loosen nuts, bolts, and drive lag screws. With the 05079 adapter and wood boring bits, the ID07 can drill up to 11/16" diameter holes in timbers without generating reactive torque, ensuring safety for divers. It also features a trigger guard and a hi-visibility yellow finish for added safety and easy identification.

ID07 UNDERWATER IMPACT DRILL

FEATURES

- Integral Stanley Hyrevz gear motor produces high torque
- Stainless Steel spool and fasteners
- Forward-Reverse with variable speed
- 500 ft lbs/675 Nm of impact torque
- Oversized trigger with guard for operator comfort
- Wiper seals on reversing and trigger spool
- Built in reverse check valve ensures long seal life
- Plastisol handle for comfortable ergonomic grip
- Forward position of handle provides better balance
- Open Center/Closed Center-Dual Spool Feature
- Cast-in lifting eye

SPECIFICATIONS

CAPACITY	1/2 IN. / 12.7 MM SQUARE DRIVE
PERFORMANCE	TORQUE 500 FT LBS / 675 NM
FLOW RANGE	4 - 12 GPM / 15 - 45 LPM
WORKING PRESSURE	750-2000 PSI / 50-140 BAR
FULL RELIEF SETTING	2100 PSI / 145 BAR
WEIGHT	7.2 LBS / 3.3 KG
LENGTH	13 IN. / 33 CM
WIDTH	5 IN. / 12.7 CM
CONNECTOR	ISO 16028 FLAT FACE COUPLER – SIZE 8

ORDER INFORMATION

PART NO.	DESCRIPTION
ID07920	IMPACT/DRILL, UNDERWATER, 1/2 IN. SQUARE DRIVE, LESS COUPLERS
ID0792001	IMPACT/DRILL, UNDERWATER, CE, 1/2 IN. SQUARE DRIVE, W/HOSE WHIPS AND COUPLERS

ACCESSORIES

PART NO.	DESCRIPTION
03971	FLUSH-FACE COUPLING SET, 3/8 IN. NPT
03974	FLUSH-FACE COUPLING SET, 1/2 IN. NPT
31848	DUAL HOSE, 50 FT x 1/25 IN. WITH COUPLERS
31972	DUAL HOSE, 25 FT x 1/2 IN., WITH COUPLERS
58633	TWINNED HOSE, 25 FT x 1/2 IN., WITH COUPLERS
58634	TWINNED HOSE, 50 FT x 1/2 IN. WITH COUPLERS

When hydraulic hose exceeds 100' (30.4 m) in length, increase I.D. of both pressure and return hose. For more information, consult STANLEY Hydraulic Tools.

STANLEY®

3810 SE Naef Road // Milwaukie, OR 97267 // 833-723-1843 // www.IndustrialToolsAndAttachments.com

2025.08.07