

STANLEY®



RS25 RAIL SAW

The RS25 Hydraulic Rail Saw with its bell-crank style clamp design provides positive, rigid locking to all types of rail for quick and accurate set-up. The ergonomic long saw arm is standard with the RS25 and allows the operator full use of the tool in a standing position. The indexable swivel on the clamp arm and saw, allows cutting on both sides of the rail, eliminating the need to disconnect from and re-connect to the saw clamp.

RS25 RAIL SAW

FEATURES AND BENEFITS

- The RS25 comes standard with an ergonomically designed long saw arm, which enables the operator to use the tool while standing, reducing fatigue and minimizing the risk of back injury
- The Full Upright Assist Handle, located over the guard, is adjustable to suit the operator's preference and can be collapsed for convenient transport and storage of the saw
- Indexable Swivel on the clamp arm and saw allows cutting on both sides of the rail, eliminating the need to disconnect from and reconnect to the saw clamp
- Available in both 14" and 16" models to match application and customer needs.

SPECIFICATIONS

CAPACITY (CUT LENGTH)	12, 15, & 20 IN. / 30, 38, & 51 CM
SAW WEIGHT	33 LBS / 15 KG
CLAMP WEIGHT	22 LBS / 9.9 KG
TOTAL WEIGHT	56 LBS / 25 KG
LENGTH	36 IN. / 92 CM
WIDTH	11 IN. / 28 CM
PRESSURE	1800 - 2000 PSI / 124 - 140 BAR
FLOW RANGE	8 - 10 GPM / 30 - 38 LPM
RPM	4000
PORTING	-8 SAE O-RING
DEPTH	18 IN / 46 CM
CONNECTOR	HTMA FLUSH FACED COUPLER

ORDER INFORMATION

MODEL NO.	DESCRIPTION
RS25103	RAIL SAW CE 16" CAPACITY
RS25103B	RAIL SAW CE 16" CAPACITY - AERO QUIP

ACCESSORIES

PART NO.	DESCRIPTION
29745	RAIL SAW BLADE - 16 IN. NORTON NORZONE III FASTCUT
22439	RAIL SAW BLADE - 16 IN. NORTON AT-36