

## DIVATOR MASKS

### FULL FACE MASKS

- ❶ High air flow capacity and low breathing resistance increases the divers performance and endurance
- ❷ Leakage is prevented by a double sealing on the exhalation valve and with a soft and flexible mask sealing
- ❸ With a low dead space volume the air consumption is minimized
- ❹ The mouthpiece can easily be drained from water with a purge button



# DIVATOR MASKS

## FULL FACE MASKS

Our best-known diving product is the **DIVATOR FULL FACE MASK** (also known as the 'AGA mask'). The **DIVATOR FULL FACE MASK** is the Worlds most sold full-face mask. Even if you are not acquainted with Interspiro, or with our products, it is quite likely that you have seen the **DIVATOR MASK** watching professional divers at work on television and in the movies.

But the real magic is not the face mask, rather is it the balanced breathing valve with its high capacity, low breathing resistance and extreme resilience to dangerous fluids. The breathing valve is the real pride of our engineering staff.

The **DIVATOR MASK** is available with varied options such as the Divator breathing valve with mouthpiece, Divator Hatch, Divator HUD, Divator Mask Weights and Divator Frames for spectacles.

Diving equipment from Interspiro is an investment with a long service life, when properly maintained. To simplify service and to obtain maximum product performance we recommend using our service kits, containing original spare parts necessary for preventive maintenance.

Interspiro offers training courses for users who perform day-to-day service work, as well as training for service personnel performing full maintenance programmes.

**For more information about the DIVATOR product range and our other diving equipment please visit us on the Internet.**

### STANDARDS

- EN 250

### APPROVALS

- CE 89/686/EEC

### DIMENSIONS AND WEIGHT

Divator mask	160x110x230 mm
Mask w breathing valve	0.8 kg
Mask w/o breathing valve	0.64 kg

### MATERIAL

Mask body	Natural rubber or Silicone
Visor	Polycarbonate
Breathing valve	Polyamide reinforced with glass fiber
Membrane	Natural rubber

### PERFORMANCE

Meet performance requirements of EN 250.  
Designed for use in cold-water dives.

Fully functional in (air) temperature range of:	-30 to +70 C°
Medium pressure range:	5-11 bar
Safety valve (built in feature) opening pressure:	12-20 bar

### CONNECTIONS

Breathing valve LP connection M16x1 male  
(hoses for alternative connections are available)

### AVAILABLE VARIANTS

Mask	Natural rubber (black and grey) Silicon (black and yellow)
Breathing valve	Without safety pressure (black and grey) With safety pressure (black and grey)

# INTERSPIRO

[www.interspiro.com](http://www.interspiro.com)

## CENTRAL EUROPE

### AUSTRIA

INTERSPIRO GesmbH [www.interspiro.de](http://www.interspiro.de)  
Sternweg 20 A-8401 ZETTLING AUSTRIA  
TEL +43 (0)313 557 333 FAX +43 (0)313 557 333 22 E-MAIL [info@interspiro.de](mailto:info@interspiro.de)

### GERMANY

INTERSPIRO GmbH [www.interspiro.de](http://www.interspiro.de)  
Postfach 1220 D-76691 FORST/BADEN GERMANY  
TEL +49 (0)7251 8030 FAX +49 (0)7251 2298 E-MAIL [info@interspiro.de](mailto:info@interspiro.de)

### SWITZERLAND

INTERSPIRO AG [www.interspiro.de](http://www.interspiro.de)  
Güterstraße 47 CH-4133 PRATTELN SWITZERLAND  
TEL +41 61 827 99 77 FAX +41 61 827 99 70 E-MAIL [info@interspiro.ch](mailto:info@interspiro.ch)

### THE NETHERLANDS & BELGIUM

INTERSPIRO BV [www.interspiro.nl](http://www.interspiro.nl)  
Televisieweg 113 NL-1322 BD ALMERE NETHERLANDS  
TEL +31 (0)36 5363103 FAX +31 (0)36 5384809 E-MAIL [infobv@interspiro.com](mailto:infobv@interspiro.com)

## NORTH & SOUTH AMERICA

INTERSPIRO Inc. [www.interspiro-us.com](http://www.interspiro-us.com)  
10225 82nd Avenue PLEASANT PRAIRIE WI 53158-5801 USA  
TEL +1 262 947 9901 FAX +1 262 947 9902 E-MAIL [sales@interspiro-us.com](mailto:sales@interspiro-us.com)

## UNITED KINGDOM & IRELAND

INTERSPIRO Ltd. [www.interspiro.com](http://www.interspiro.com)  
7 Hawksworth Road Central Park TELFORD Shropshire TF2 9TU UNITED KINGDOM  
TEL +44 (0)1952 200 190 FAX +44 (0)1952 299 805 E-MAIL [infouk@interspiro.com](mailto:infouk@interspiro.com)

## SCANDINAVIA, ASIA/PACIFIC & MIDDLE EAST

### SWEDEN

NORDIC & EXPORT SALES DIVISION [www.interspiro.com](http://www.interspiro.com)  
Box 10060 S-181 10 LIDINGÖ SWEDEN  
TEL +46 8 636 51 00 FAX +46 8 765 48 53 E-MAIL [info@interspiro.com](mailto:info@interspiro.com)

### MALAYSIA

NORDIC & EXPORT SALES DIVISION [www.interspiro.com](http://www.interspiro.com)  
305 & 305A Lorong Perak Taman Melawati 53100 KUALA LUMPUR MALAYSIA  
TEL +60 3 4105 8122 FAX +60 3 4105 3122 E-MAIL [asiapacific@interspiro.com](mailto:asiapacific@interspiro.com)