

AMCOMMAND I PANEL CALL-OUT

Communications

The 2810A communicator comes complete with a Hand-Held Push-to-Talk microphone which cancels topside background noise and provides clear communication to the diver.

Low Pressure Side

Input check valve permits simple switching to back-up high pressure air in the event of low pressure air failure.

Air Control

Two high pressure supply connections with two color coded, 6 ft. SCUBA yokes and whips. The whips and yokes remain attached to the lid of the unit during storage or transit.



Pneumo System

The heart of the Pneumo System is the high precision 6 in. depth gauge. The gauge dial has a glare free face and is clearly marked for fast, accurate readings. Accuracy is .25%, full scale. The system has a built-in snubber for reducing pulsating and shock pressure loads to the precision gauges. Diver's Pneumo connection is O₂.

Diver's Umbilical Connection

Diver's umbilical air connection is an O₂ fitting, controlled by a quarter turn ball valve which permits unrestricted flow. Safety relief valve factory set at 285 PSI.

THE CASE

- Pressure Equalization Valve
- Easy Open Double Throw Latches
- Watertight O-Ring Seal
- Stainless Steel Hinge Pins with Heavy Duty Deflector Ribs
- Rubber Over-Molded Handle
- Stainless Steel Padlock Protectors
- Co-Polymer Composite Material



Digital Timer / Clock

BD-CT

- Countdown timer with alarm and time-out function - 23 hrs, 59 min., 59 sec. to 0
- Stopwatch - 0 to 23 hrs, 59 min., 59 sec.
- Real-time clock

Specifications

| | |
|-----------------|---------------------------------------|
| Dimensions | 5-1/2 in. H x 3-3/4 in. W x 3/4 in. D |
| Digital Display | 2-1/2 in. |

