

Professional Weight Belt

WB-500

This belt is produced to give many years of rugged commercial use, with practicability and comfort in mind. The quick release buckle is cast from manganese bronze, for marine environment use and strength. 300 series stainless springs; spacers and pins are used on the closing and release mechanism. The buckle maybe released easily while wearing thick gloves or dry mitts.

Features

- Heavy 1/8 in. thick by 2 in. shoulder webbing with heavy stainless adjusters
- Dura-Soft Nylon webbing for comfort and minimizing chafing
- All metal components are non-magnetic 300 series stainless steel with exception of weights and bronze buckle
- Durable rubber belting reinforced with 2 ply nylon
- Adjustable waist size, weight requirements, and shoulder strap length
- Belt dimensions: 48 in. long by 4-1/2 in. wide by 1/4 in. thick



Professional Weight Belts

WB-500-X	Weight Belt without weights
WB-500-A	Weight Belt with four 8 lb weights (32 lbs)
WB-500-B	Weight Belt with five 5 lb weights (25 lbs)
WB-500-C	Weight Belt with six 3 lb weights (18 lbs)



MK-20 Mod O Harness

AMK20H

US Navy approved harness with 2 inch nylon webbing with adjustable shoulder straps. Single point lifting D-ring, integrated adjustable chest strap and jock strap with quick release straps.

Features

- US Navy approved harness under approval # 3.1.1
- 2 in. nylon webbing with adjustable shoulder straps
- Single point lifting D-ring
- Integrated adjustable jock strap with quick release snaps
- Adjustable chest strap
- Adjustable split jock strap



Full Body Harness

NSBB-16510-SIZE

Full Body Harness with 2 piece jock strap for commercial diving.

Features

- Built in two-piece jock strap
- Shoulder adjusters included
- Jock strap adjusters included
- Chest Strap
- Cam-lock (to secure tank)
- Extra pair of D-rings
- Sizes available: S-XL



Accessories

BH-200-SA-(SIZE)	Bell Harness with Shoulder Adjusters
JS-800	Optional Jock Strap

Bell Harness

BH-200-(SIZE)

This harness is set up for Bell diving, with rear upper D-ring for emergency lifting of diver. Two front D-rings provide hookups for air, or gas hose. A heavy duty belt adjuster is provided for the optional jock strap.

Features

- Two front D-rings
- One upper rear D-ring for emergency lifting
- Heavy duty belt adjuster provided for optional jock strap
- Shoulder adjusters included
- Jock strap adjusters included
- Chest Strap
- Extra pair of D-rings
- Sizes available: S-XL